

DA-720 Series Linux Software User's Manual

Edition 3.0, November 2018

www.moxa.com/product



© 2018 Moxa Inc. All rights reserved.

DA-720 Series Linux Software

User's Manual

The software described in this manual is furnished under a license agreement and may be used only in accordance with the terms of that agreement.

Copyright Notice

© 2018 Moxa Inc. All rights reserved.

Trademarks

The MOXA logo is a registered trademark of Moxa Inc.

All other trademarks or registered marks in this manual belong to their respective manufacturers.

Disclaimer

Information in this document is subject to change without notice and does not represent a commitment on the part of Moxa.

Moxa provides this document as is, without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. Moxa reserves the right to make improvements and/or changes to this manual, or to the products and/or the programs described in this manual, at any time.

Information provided in this manual is intended to be accurate and reliable. However, Moxa assumes no responsibility for its use, or for any infringements on the rights of third parties that may result from its use.

This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

Technical Support Contact Information

www.moxa.com/support

Moxa Americas

Toll-free: 1-888-669-2872
Tel: +1-714-528-6777
Fax: +1-714-528-6778

Moxa Europe

Tel: +49-89-3 70 03 99-0
Fax: +49-89-3 70 03 99-99

Moxa India

Tel: +91-80-4172-9088
Fax: +91-80-4132-1045

Moxa China (Shanghai office)

Toll-free: 800-820-5036
Tel: +86-21-5258-9955
Fax: +86-21-5258-5505

Moxa Asia-Pacific

Tel: +886-2-8919-1230
Fax: +886-2-8919-1231

Table of Contents

1. Introduction	1-1
Overview	1-2
Software Specifications.....	1-2
Software Components	1-3
2. Software Configuration	2-1
Account Management.....	2-2
Starting from a VGA Console.....	2-3
Setting up Desktop Environments.....	2-3
Connecting from an SSH Console.....	2-4
Windows Users	2-5
Linux Users	2-5
Adjusting the System Time	2-5
Setting the Time Manually	2-6
NTP Client	2-6
Updating the Time Automatically	2-7
Enabling and Disabling Daemons	2-7
Executing Scheduled Commands Using the Cron Daemon	2-9
Inserting a USB Storage Device into the Computer	2-10
Checking the Linux Version	2-11
Installing and Removing Packages Using APT	2-11
Setting Up a Desktop Environment.....	2-13
Power Management—Suspend.....	2-14
Wake On LAN	2-14
3. Managing Communications	3-1
Renaming the Network Interfaces	3-2
Changing the Network Settings	3-2
Editing the Interfaces Configuration File	3-2
Adjusting IP Addresses with “ifconfig”	3-5
DNS Client	3-5
/etc/hostname	3-5
/etc/resolv.conf	3-5
/etc/nsswitch.conf	3-6
Configuring Ethernet Bonding.....	3-6
Apache Web Server.....	3-8
Install the apache web server	3-8
Default Homepage.....	3-8
IPTABLES	3-8
IPTABLES Hierarchy	3-9
iptables Modules	3-10
Observe and Erase Chain Rules	3-11
Define Policy for Chain Rules.....	3-12
Append or Delete Rules	3-12
NAT (Network Address Translation).....	3-13
NAT Example	3-13
Enabling NAT at Bootup.....	3-14
PPP (Point-to-Point Protocol)	3-15
Connecting to a PPP Server over a Simple Dial-up Connection.....	3-15
Connecting to a PPP Server over a Hard-wired Link.....	3-16
Checking the Connection	3-17
Setting up a Machine for Incoming PPP Connections	3-18
PPPoE.....	3-19
NFS (Network File System) Client	3-21
SNMP (Simple Network Management Protocol)	3-22
OpenVPN	3-23
Install the openvpn.....	3-23
Ethernet Bridging for Private Networks on Different Subnets.....	3-24
Ethernet Bridging for Private Networks on the Same Subnet	3-27
Routed IP	3-28
4. Programming Guide	4-1
Device API	4-2
RTC (Real Time Clock).....	4-2
UART	4-2
Programmable LED, Power Indicator, and Relay control	4-3
WDT (Watch Dog Timer).....	4-4
Introduction.....	4-4
Watchdog Usage	4-4
How the WDT Works	4-4

The Watchdog Device IOCTL Commands	4-6
Examples	4-7
5. System Recovery.....	5-1
Recovery Environment	5-2
Recovery Procedure	5-2
6. DA-720 Expansion Module.....	6-1
DE-PRP-HSR-EF.....	6-2
Installing the HSR/PRP Module Utility.....	6-2
The HSR/PRP Module Utility	6-3
DE-2-IRIGB-4-DI/DO	6-7
Installing the IRIG-B Driver in Linux	6-7
Using the timesync Daemon in Linux	6-9
Using the IRIG-B Utility in Linux.....	6-10
A. Software Components	A-1

1

Introduction

Thank you for purchasing a Moxa DA-720 series x86, ready-to-run embedded computer. This manual describes the software configuration and management process for the DA-720 Linux models. For details regarding hardware installation, connector interfaces, setup, and BIOS upgrade, refer to the *DA-720 Series Hardware User's Manual*.

Linux is an open, scalable operating system that allows you to build a wide range of innovative, small-footprint devices. Software written for desktop PCs can be easily ported to the embedded computer with a GNU cross compiler and minimum source-code modifications. A typical Linux-based device is designed for a specific use. It is often not connected to other computers. A number of such devices connect to a centralized front-end host. Examples include enterprise tools such as industrial controllers, communications hubs, point-of-sale terminals, and display devices, which include HMIs, advertisement appliances, and interactive panels.

The following topics are covered in this chapter:

- Overview**
- Software Specifications**
- Software Components**

Overview


The DA-720 series of computers are x86 platforms with VGA/DVI, mSATA, and SATA interfaces, 14 Gigabit Ethernet ports, 2 USB 2.0 and 2 USB 3.0 hosts, and two PCI-e ports for expansion modules.

The robust design of the DA-720 computers makes them ideal for use in specialized industrial automation applications such as power substations, transportation and shipping, and oil and gas production and supply. The DA-720 computers can run on Linux or Windows, providing a user-friendly environment for developing sophisticated application software. Moxa's ready-to-run software and readily available after-service support makes the programmer's job easier by helping them develop bug-free code quickly and at a lower cost.

The DA-720 comes with 2 PCI-e ports for expansion modules. Moxa provides a variety of communication expansion modules, including an 8-port RS-232/422/485 module, a 4-port 10/100/1000 Mbps LAN module, and an 8-port 10/100/1000 Mbps LAN module. The user-friendly design gives the advantage of quick and easy module swaps. These features make the DA-720 an ideal for use in a wide array of industrial automation applications.

Software Specifications

The Linux operating system preinstalled on the DA-720 embedded computers is a **Debian Jessie** distribution. The Debian project consists of a group of volunteers located worldwide who endeavor to produce an operating system distribution composed entirely of free software. The Debian GNU/Linux follows the standard Linux architecture, making it easy to use programs that meet the POSIX standard. You can use the GNU Tool Chain provided by Moxa to port programs on to the Debian Linux platform. In addition to standard POSIX APIs, device drivers for Moxa UART and other peripherals such as programmable LEDs and relay are also included along with the Linux operating system. An example that represents the software architecture is shown below:



ATTENTION

The above software architecture is only an example. Different models or different build revisions of the Linux operating system may include components not shown in this illustration.

ATTENTION

 For information and documentation regarding Debian GNU/Linux and the free software concept, refer to the following links:

- <http://www.debian.org/>
- <http://www.gnu.org/>

Software Components

The DA-720 Linux models are preinstalled with the Debian Jessie Linux distribution. For a complete list of the software components, refer to *Appendix A*.

2

Software Configuration

There are three ways to connect to the DA-720 Linux model computer from a desktop: through a VGA monitor, and via an SSH over the network console from a Windows or Linux machine. These three methods are explained in this chapter. Only basic Linux operating system configurations on the DA-720 Linux model are covered here. For advanced network configuration and management instructions refer to *Chapter 3, Managing Communications*.

The following topics are covered in this chapter:

- **Account Management**
- **Starting from a VGA Console**
- **Setting up Desktop Environments**
- **Connecting from an SSH Console**
 - Windows Users
 - Linux Users
- **Adjusting the System Time**
 - Setting the Time Manually
 - NTP Client
 - Updating the Time Automatically
- **Enabling and Disabling Daemons**
- **Executing Scheduled Commands Using the Cron Daemon**
- **Inserting a USB Storage Device into the Computer**
- **Checking the Linux Version**
- **Installing and Removing Packages Using APT**
- **Setting Up a Desktop Environment**
- **Power Management—Suspend**
- **Wake On LAN**

In addition, use `sudo -i` to login as root to have more privileges.

```
moxa@Moxa:~# sudo -i  
[sudo] password for moxa:  
root@Moxa:~$
```

Starting from a VGA Console

Connect the display monitor to the DA-720-LX and power it up connecting the power adaptor. It takes approximately 30 to 60 seconds for the system to boot up. Once the system is ready, a login screen will appear on your monitor.

To log in, type the login name and password as requested. The default values are both **moxa**.

Login: moxa

Password: moxa

```
Moxa login: moxa  
Password:  
  
#####      #####      #####      #####      #####      ##  
###      #####      ###      ###      #####      #####      ###  
###      ###      ###      ###      ###      ##      ###  
###      #####      ##      ##      #####      #      #####  
###      #      ##      ###      ##      #####      ##      ##  
##      ##      #      ##      ##      ##      #####      ##  
##      ##      #      ##      ##      ##      #####      ##  
##      ##      #      ##      ##      ##      #####      ##  
##      ##      #      ##      ##      ##      #####      ##  
##      ##      #      ##      ##      ##      #####      ##  
##      ##      #      ##      ##      ##      #####      ##  
##      ##      #      ##      ##      ##      #####      ##  
##      ##      #      ##      ##      ##      #####      ##  
##      ##      #      ##      ##      ##      #####      ##  
##      ##      #      ##      ##      ##      #####      ##  
##      ##      #      ##      ##      ##      #####      ##  
#####      #      #####      #####      #####      #####      #####  
  
For further information check:  
http://www.moxa.com/
```

Setting up Desktop Environments

In this section we discuss how to setup various desktop environments on the DA-720 computer. By default, the DA-720 Linux operating system doesn't install a desktop environment. However, Debian supports various full-fledged graphical environments such as Gnome, KDE as well as lighter environments like Xfce and LXDE. You can install one of these desktop systems on the DA-720.

To install Gnome use the following command:

```
moxa@Moxa:~# sudo apt-get install gnome
```

To install KDE use the following commands:

```
moxa@Moxa:~# sudo apt-get install aptitude tasksel  
moxa@Moxa:~# sudo aptitude install ~t^desktop$ ~t^kde-desktop$
```

To install Xfce use the following command:

```
moxa@Moxa:~# sudo apt-get install xfce4 xfce4-goodies task-xfce-desktop
```

To install the minimum LXDE environment use the following command:

```
moxa@Moxa:~# sudo apt-get install lxde-core lxde
```

Connecting from an SSH Console

You can use an SSH console on your workstation/PC to connect to the DA-720 computers. SSH connections are believed to provide better network security as compared to Telnet connections. The default IP addresses and netmasks of the network interfaces are as follows:

	Default IP Address	Netmask
LAN1	192.168.3.127	255.255.255.0
LAN2	192.168.4.127	255.255.255.0
LAN3	192.168.5.127	255.255.255.0
LAN4	192.168.6.127	255.255.255.0
LAN5	192.168.7.127	255.255.255.0
LAN6	192.168.8.127	255.255.255.0
LAN7	192.168.9.127	255.255.255.0
LAN8	192.168.10.127	255.255.255.0
LAN9	192.168.11.127	255.255.255.0
LAN10	192.168.12.127	255.255.255.0
LAN11	192.168.13.127	255.255.255.0
LAN12	192.168.14.127	255.255.255.0
LAN13	192.168.15.127	255.255.255.0
LAN14	192.168.16.127	255.255.255.0

Before using the SSH client, you should change the IP address of your development workstation so that its network ports are on the same subnet as the IP address for the LAN port that you will connect to. For example, if you will connect to LAN1, you could set your PC's IP address to 192.168.3.126, and the netmask to 255.255.255.0. If you will connect to LAN2, you could set your PC's IP address to 192.168.4.126, and the netmask to 255.255.255.0.

Use a cross-over Ethernet cable to connect your development workstation directly to the DA-720, or use a straight-through Ethernet cable to connect the DA-720 to a LAN hub or switch. Use an SSH client installed on your development workstation to connect to the DA-720. After a connection has been established, type the login and password as requested to log on to the DA-720. The default values are both **moxa**.


Login: moxa

Password: moxa

Windows Users

To set up an SSH console for the DA-720 in a Windows environment, use the **PuTTY** application available for free at: <http://www.chiark.greenend.org.uk/~sgtatham/putty/download.html>

The following screenshot shows an example of the configuration that is required in **PuTTY**:



Linux Users

To access the DA-720-LX's console utility via SSH from a Linux machine, use the **ssh** command as follows:

```
#ssh moxa@192.168.3.127
```

Type **yes** to open the connection.

```
[root@Jim_notebook root]# ssh 192.168.3.127
The authenticity of host '192.168.3.127 (192.168.3.127)' can't be established.
RSA key fingerprint is 8b:ee:ff:84:41:25:fc:cd:2a:f2:92:8f:cb:1f:6b:2f.
Are you sure you want to continue connection (yes/no)? yes_
```

Adjusting the System Time

The DA-720 has two time settings: The system time, and the time of the RTC (Real Time Clock) built into the DA-720 hardware.

Setting the Time Manually

Use the `date` command to query the current system time or to set a new system time.

```
# date MMDDhhmmYYYY
```

MM:	Month
DD:	Date
hhmm:	Hour and Minute
YYYY:	Year

Use the `hwclock` command to query the current RTC time or to set a new RTC time.

Use the following command to write the current system time to the RTC:

```
# hwclock -w
```

```
root@Moxa:~# date
Wed Dec 16 03:34:46 CST 2016
root@Moxa:~# hwclock
Wed 16 Dec 2016 03:35:16 AM CST -0.017600 seconds
root@Moxa:~# date 121616352016
Wed Dec 16 16:35:00 CST 2016
root@Moxa:~# hwclock -w
root@Moxa:~# date ; hwclock
Wed Dec 16 16:36:12 CST 2016
Wed 16 Dec 2016 03:38:13 AM CST -0.016751 seconds
root@Moxa:~#
```

NTP Client

The DA-720 can use a NTP (Network Time Protocol) client to initialize a time request to a remote NTP server, which you can install using the following command:

```
# apt-get install ntpdate
```

Use the `ntpdate` command to update the system time

```
# ntpdate time.stdtime.gov.tw
# hwclock -w
```

```
root@Moxa:~# date ; hwclock
Wed Dec 16 16:36:12 CST 2016
Wed 16 Dec 2016 03:38:13 AM CST -0.016751 seconds
root@Moxa:~#
root@Moxa:~# ntpdate time.stdtime.gov.tw
16 Dec 03:49:48 ntpdate[2510]: step time server 220.130.158.52 offset 155905087.9
84256 sec
root@Moxa:~#
root@Moxa:~# hwclock -w
root@Moxa:~# date ; hwclock
Wed Dec 16 03:51:07 CST 2016
Wed 16 Dec 2016 03:51:07 AM CST -0.016771 seconds
root@Moxa:~#
```

For more information on NTP and NTP server addresses, visit <http://www.ntp.org>.

ATTENTION

Before using the NTP client utility, check your IP address and network settings (gateway and DNS) to make sure an Internet connection is available.

Updating the Time Automatically

This section describes how to use a shell scripts to automatically update the system time.

Example Shell Script for Periodically Updating the System Time

```
#!/bin/sh
ntpdate time.stdtime.gov.tw
# You can use the time server's ip address or domain
# name directly. If you use domain name, you must
# enable the domain client on the system by updating
# /etc/resolv.conf file.
hwclock -w
sleep 100
# Updates every 100 seconds. The min. time is 100 seconds.
# Change 100 to a larger number to update RTC less often.
```

You can save this shell script using any file name. Let's call it **fixtime**.

How to run the shell script automatically when the kernel boots up

Copy the example shell script **fixtime** to the directory **/etc/init.d**, and then use the following command to change the shell script mode:

```
# chmod 755 fixtime
```

Use the **vi** editor to edit the **/etc/inittab** file as follows:

```
# vi /etc/inittab
```

At the end of the script add the following line:

```
ntp : 2345 : respawn : /etc/init.d/fixtime
```

Use the **#init q** command to re-initialize the kernel.

```
# init q
```

Enabling and Disabling Daemons

By default, the following daemons are enabled in the DA-720-LX:

sftpd SFTP Server / Client daemon
sshd Secure Shell Server daemon

You can manage the services that you want to run in the background using the **insserv** command.

The following example shows how to add the apache daemon to the current run level:

```
moxa@Moxa:~$ sudo insserv -d apache2
```

The apache daemon will not be activated in current boot session, but will run in the background starting with the next boot session.

To disable the apache daemon, use the following command:

```
moxa@Moxa:~$ sudo insserv -r apache2
```

Linux daemons can be started or stopped in the current boot session by using of the scripts in the **/etc/init.d** file.

To start the apache daemon in the current boot session, use the following command:

```
moxa@Moxa:~$ sudo /etc/init.d/apache2 start
```

To stop the apache daemon, use the following command:

```
moxa@Moxa:~$ sudo /etc/init.d/apache2 stop
```

You can use the management utility called **systemctl** to list all services running at any time as follows:

```
moxa@Moxa:~$ sudo systemctl
```

The **apache2** daemon is another service that you can activate in the current boot session.

To enable the **apache2** service, use the following command:

```
moxa@Moxa:~$ sudo systemctl enable apache2
```

To disable the **apache2** service, use the following command:

```
moxa@Moxa:~$ sudo systemctl disable apache2
```

Linux daemons can also be started or stopped using the **systemctl** command.

To start the **apache2** daemon, use the following command:

```
moxa@Moxa:~$ sudo systemctl start apache2
```

To stop the **apache2** service, use the following command:

```
moxa@Moxa:~$ sudo systemctl stop apache2
```

To restart the **apache2** service, use the following command:

```
moxa@Moxa:~$ sudo systemctl restart apache2
```

To show the status of **apache2** service, use the following command:

```
moxa@Moxa:~$ sudo systemctl status apache2
```

To run a private daemon, you can edit the file **rc.local**, as shown below:

1. Type **cd /etc/** to change directory.

```
root@Moxa:~# cd /etc/
```

2. Type **vi rc.local** to edit the configuration file using the **vi** editor.

```
root@Moxa:/etc/# vi rc.local
```

3. Add the application daemon that you want to run to the **rc.local** file.

Here we use the example of the **tcp2-release** program, which you can find on the CD, to illustrate how to configure and run a service as a background process.

```
#!/bin/sh  
# Add the daemon that you want to run  
/root/tcp2-release &
```

4. After rebooting the system, you can find the daemon that you enabled by running the `ps` command.

```
root@Moxa:~# ps -ef
  PID  Uid      VmSize Stat  Command
    1  root        1296 S    init
    2  root          S  [keventd]
    3  root          S  [ksoftirqd_CPU0]
    4  root          S  [kswapd]
    5  root          S  [bdflush]
    6  root          S  [kupdated]
    7  root          S  [mtdblockd]
    8  root          S  [khubd]
   10  root          S  [jffs2_gcd_mtd3]
   32  root          D  [ixp425_csr]
   38  root        1256 S  stdef
   47  root        1368 S  /usr/sbin/apache2
   53  root        4464 S  /usr/sbin/httpd
   63  nobody      4480 S  /usr/sbin/httpd
   64  nobody      4480 S  /usr/sbin/httpd
   65  nobody      4480 S  /usr/sbin/httpd
   66  nobody      4480 S  /usr/sbin/httpd
   67  nobody      4480 S  /usr/sbin/httpd
   92  bin         1460 S  /sbin/portmap
   97  root        1264 S  /root/tcps2-release
  105  root        1556 S  /usr/sbin/rpc.statd
  109  root        4044 S  /usr/sbin/snmpd -s -l  /dev/null
  111  root        2832 S  /usr/sbin/snmptrapd -s
  140  root        1364 S  /sbin/cardmgr
  144  root        1756 S  /usr/sbin/rpc.nfsd
  146  root        1780 S  /usr/sbin/rpc.mountd
  153  root        2960 S  /usr/sbin/sshd
  161  root        1272 S  /bin/reportip
  162  root        3464 S  /bin/massupfirm
  163  root        1532 S  /sbin/getty 115200 ttys0
  164  root        1532 S  /sbin/getty 115200 ttys1
  166  root        3464 S  /bin/massupfirm
  168  root        3464 S  /bin/massupfirm
  171  root        3652 S  /usr/sbin/sshd
  172  root        2200 S  -bash
  174  root        1592 S  ps -ef
root@Moxa:~#
```

Executing Scheduled Commands Using the Cron Daemon

The `cron` daemon is used to run scheduled tasks in a Linux environment. When the `cron` daemon is running in the background, it searches the `/etc/crontab` file, **every minute**, to check each command to see if it should be run at that time. The output of the commands that are run is sent to the owner of the `crontab` or to the user named in the `MAILTO` environment variable in the `crontab`, if such a user exists.

To set up your scheduled applications, you must modify the **/etc/crontab** file. The **crontab** entries have the following format:

Mm	h	dom	mon	Dow	user	command
minute	hour	date	month	Week	user	command
0-59	0-23	1-31	1-12	0-6 (0 is Sunday)		

For example, add an entry to the **crontab** file in the format specified below if you want to launch a program at 8:00 every day:

```
#minute hour date month week user command
*      8     *     *     *     root  /path/to/your/program
```

The following example demonstrates how to use the **cron** service to update the system time and RTC time at 8:00 AM every day:

1. Write the following shell script and save it as **fixtime.sh** in the **/home/** folder:

```
#!/bin/sh
ntpdate time.stdtime.gov.tw
hwclock -w
exit 0
```

2. Change the mode of **fixtime.sh**

```
# chmod 755 fixtime.sh
```

3. Modify the **/etc/crontab** file to run **fixtime.sh** at 8:00 every day by adding the following line to the end of **crontab** content:

```
* 8 * * * root  /home/fixtime.sh
```

Inserting a USB Storage Device into the Computer

By default, the USB storage devices are automatically mounted on to the DA-720. If you want to manually mount a device on to the DA-720, refer to the following instructions:

```
root@Moxa:~# dmesg
...
[ 712.833903] usb 1-1.1: Product: Mass Storage Device
[ 712.833916] usb 1-1.1: Manufacturer: JetFlash
[ 712.833929] usb 1-1.1: SerialNumber: 819KM6NSI94DAIM6
[ 712.859561] usb-storage 1-1.1:1.0: USB Mass Storage device detected
[ 712.861103] scsi2 : usb-storage 1-1.1:1.0
[ 712.861626] usbcore: registered new interface driver usb-storage
[ 714.040211] scsi 2:0:0:0: Direct-Access      JetFlash Transcend 8GB    1100 PQ: 0
ANSI: 4
[ 714.041969] sd 2:0:0:0: Attached scsi generic sg1 type 0
[ 714.043479] sd 2:0:0:0: [sdb] 15826944 512-byte logical blocks: (8.10 GB/7.54 GiB)
[ 714.044453] sd 2:0:0:0: [sdb] Write Protect is off
[ 714.044476] sd 2:0:0:0: [sdb] Mode Sense: 43 00 00 00
[ 714.045599] sd 2:0:0:0: [sdb] No Caching mode page found
[ 714.045844] sd 2:0:0:0: [sdb] Assuming drive cache: write through
[ 714.053410] sdb: sdb1
[ 714.057663] sd 2:0:0:0: [sdb] Attached SCSI removable disk
```

A USB storage drive is assigned the name **sdb**. The first USB partition can be mounted using **/dev/sdb1** as follows:

```
root@Moxa:~# mount /dev/sdb1 /mnt
```

To check if a USB device is mounted do the following:

```
root@debian:~# mount
sysfs on /sys type sysfs (rw,nosuid,nodev,noexec,relatime)
proc on /proc type proc (rw,nosuid,nodev,noexec,relatime)
udev on /dev type devtmpfs (rw,relatime,size=10240k,nr_inodes=241983,mode=755)
devpts on /dev/pts type devpts
(rw,nosuid,noexec,relatime,gid=5,mode=620,ptmxmode=000)
tmpfs on /run type tmpfs (rw,nosuid,noexec,relatime,size=195144k,mode=755)
/dev/sda1 on / type ext4 (rw,relatime,errors=remount-ro,data=ordered)
tmpfs on /run/lock type tmpfs (rw,nosuid,nodev,noexec,relatime,size=5120k)
tmpfs on /run/shm type tmpfs (rw,nosuid,nodev,noexec,relatime,size=390280k)
/dev/sdb1 on /mnt type vfat
(rw,relatime,fmask=0022,dmask=0022,codepage=437,iocharset=utf8,shortname=mixed,
errors=remount-ro)
```

Once it is mounted, you can access the files on the USB storage using the path:**/mnt**

When a USB storage device is not in use, always unmount it before you unplug the device.

```
root@Moxa:~# umount /mnt
```

Checking the Linux Version

The **uname** command, short for UNIX name, prints the name, version, and other details of the operating system running on the current computer. Use the **-a** option to see the information in the following format:

```
moxa@Moxa:~# uname -a
Linux Moxa 4.6.0-0.bpo.1-amd64 #1 SMP Debian 4.6.4-1+bpo8+1 (2016-08-11) x86_64
GNU/Linux
```

Installing and Removing Packages Using APT

The advance package tool (APT) is a Debian tool used to install and remove packages. Before you use this tool to install a package, you need to configure the apt source file.

1. Use the **vi** editor to configure the apt source file **/etc/apt/sources.list** as follows:

```
root@Moxa:~# vi /etc/apt/sources.list

deb http://ftp.us.debian.org/debian/ jessie main
deb-src http://ftp.us.debian.org/debian/ jessie main

deb http://security.debian.org/ jessie/updates main
deb-src http://security.debian.org/ jessie/updates main

# jessie-updates, previously known as 'volatile'
deb http://ftp.us.debian.org/debian/ jessie-updates main
deb-src http://ftp.us.debian.org/debian/ jessie-updates main

deb http://ftp.debian.org/debian jessie-backports main
```

```
deb-src http://ftp.debian.org/debian jessie-backports main

# Moxa's update
deb http://debian.moxa.com/debian jessie main
#deb http://220.135.161.42/debian jessie main
```

2. Add Moxa's **apt** repository to **/etc/apt/sources.list**

To enable you to add or update the drivers, libraries, and utility packages provided by Moxa, we have already included the "deb http://debian.moxa.com/debian jessie main" in the **source list** by default. If it is deleted or not available for some reason, you should add these to the source list before you add Moxa's **apt** repository.

```
root@Moxa:~# sudo vi /etc/apt/sources.list
deb http://debian.moxa.com/debian jessie main
```

ATTENTION!



Moxa has encrypted its packages with a GPG key, which allows you to check if a package is verified by us. Hence, you must first upload the GPG key to the Moxa's embedded computer and add it to the GPG key list before installing the packages. You can find the GPG key in the CD/DVD or on the Moxa website.

You can check if the GPG key is already uploaded to your computer by checking the key list as follows:

```
root@Moxa:~# apt-key list
/etc/apt/trusted.gpg
-----
pub 2048R/62B24532 2014-05-28 [expires: 2024-05-25]
uid MOXA SYS <sys.support@moxa.com>
sub 2048R/F7F3CD9E 2014-05-28 [expires: 2024-05-25]
```

The GPG key will be displayed using **MOXA SYS**. If you do not find the GPG key, you can add it to the GPG key list as follows:

```
root@Moxa:~# apt-key add NEW-MOXA-SYS-DEBIAN-KEY
```

You must then update the package list as follows:

```
root@Moxa:~# apt-get update
Ign http://debian.moxa.com jessie Release.gpg
Ign http://debian.moxa.com/debian/ jessie/main Translation-en
Ign http://debian.moxa.com/debian/ jessie/main Translation-en_HK
Get:1 http://debian.moxa.com jessie Release [1,633 B]
Ign http://debian.moxa.com jessie/main i386 Packages
Get:2 http://debian.moxa.com jessie/main i386 Packages [1,585 B]
Fetched 3,218 B in 0s (47.2 kB/s)
Reading package lists... Done
```

3. After updating the package list, you can use the **apt-get** command to install or upgrade the packages from Moxa's **apt** repository as follows:

- a) Update the source list after you configure it.

```
moxa@Moxa:~# sudo apt-get update
moxa@Moxa:~#
```

- b) Once you indicate which package you want to install (**ipsec-tools**, for example), type:

```
moxa@Moxa:~# sudo apt-get install ipsec-tools
moxa@Moxa:~#
```

Use one of the following commands to remove a package:

- a. For a simple package removal:

```
moxa@Moxa:~# sudo apt-get remove ipsec-tools  
moxa@Moxa:~#
```

- b. For a complete package removal:

```
moxa@Moxa:~# sudo apt-get remove ipsec-tools --purge  
moxa@Moxa:~#
```

ATTENTION

You can free up the cache space with the `# apt-get clean` command.

```
moxa@Moxa:~# apt-get clean  
moxa@Moxa:~#
```

Setting Up a Desktop Environment

The DA-720 Linux operating system by default doesn't install a desktop environment. Debian supports multiple fully-featured graphical environments, such as Gnome, KDE, and lighter environment like Xfce and LXDE. You can choose to install one of these desktop systems on your DA-720.

To install the Gnome environment, run the following command:

```
moxa@Moxa:~# sudo apt-get install gnome
```

To install the KDE environment, run the following command:

```
moxa@Moxa:~# sudo apt-get install kde-standard
```

To install the Xfce environment, run the following command:

```
moxa@Moxa:~# apt-get install xfce4 xfce4-goodies thunar-archive-plugin
```

To install the minimum LXDE environment, run the following command:

```
moxa@Moxa:~# sudo apt-get install lxde-core lxde
```

ATTENTION

You must remove the package after the GUI installation is complete using the `# apt-get remove xserver-xorg-video-intel` command.

Power Management—Suspend

The DA-720 supports the power management function ACPI S3 (suspend to RAM). To enable this support, you must first enable the S3 option in the BIOS and then use the following command:

```
Moxa:~# pm-suspend --quirk-s3-bios
```

Once the **suspend** command is in effect, you can use the power button to wake up the computer.

In X Windows, an administrator (root) user can use the **System → Shutdown → Suspend** function to suspend a device. This function is not available to non-root users.

When Moxa's embedded computers come out of a suspended state, some application components may need to be reset. You can write a simple script in the **/usr/lib/pm-utils/sleep.d/** folder to perform this procedure as demonstrated in the following example, **script 99serial**:

```
#!/bin/sh

case "$1" in
    hibernate|suspend)
        echo "close AP and tty ports which are opened"
        echo "operations before serial ports suspend"
        ;;
    thaw|resume)
        echo "restart AP"
        echo "operations after serial ports resume"
        ;;
    *) exit $NA
        ;;
esac
```

NOTE To run this script, start **rsyslogd** using the command **/etc/init.d/rsyslogd start** and then view the file **/var/log/pm-suspend.log** to see the event log

Wake On LAN

The DA-720 supports wake on LAN (WOL), a feature used to wake up a device for suspend (S3) and shutdown (S5) states.

To check the WOL support on Ethernet port x, type **ethtool ethx**, where "x" is the port number.

```
Moxa:/# ethtool eth0
Settings for eth0:
Supported ports: [ TP ]
Supported link modes:  10baseT/Half 10baseT/Full
                           100baseT/Half 100baseT/Full
                           1000baseT/Full
Supports auto-negotiation: Yes
Advertised link modes:  10baseT/Half 10baseT/Full
                           100baseT/Half 100baseT/Full
                           1000baseT/Full
Advertised auto-negotiation: Yes
Speed: 100Mb/s
Duplex: Full
Port: Twisted Pair
```

```
PHYAD: 0
Transceiver: internal
Auto-negotiation: on
Supports Wake-on: pumbg
Wake-on: g
Current message level: 0x00000033 (51)
Link detected: yes
Moxa:/#
```

The default WOL support parameter is "g" (wake on Magic packet).

If the WOL setting is not **g**, we suggest that you modify the setting using the **ethtool -s ethx wol g** command.

The following example illustrates how to suspend (S3) your computer and how to wake it up using another computer:

1. On Moxa's embedded computer:

- i. Enable the **s3** options in the BIOS
- ii. Get the MAC address using the **ifconfig ethx** (x is the port number) command
- iii. Suspend to RAM using the **pm-suspend --quirk-s3-bios** command

2. On a remote computer:

Run the **etherwake -b mac_of_the_Moxa_computer** command to wake Moxa's embedded computer.

For example:

```
etherwake -b 00:90:e8:00:d7:07
```

The following example illustrates how to shutdown (S5) your computer and how to wake it up using another computer:

1. On Moxa's embedded computer:

Shut down your computer using the **shutdown -h now** command

2. On a remote computer

Run the **etherwake -b mac_of_the_Moxa_computer** command to wake Moxa's embedded computer.

For example:

```
etherwake -b 00:90:e8:00:d7:07
```

Managing Communications

The DA-720-LX ready-to-run embedded computer is a network-centric platform designed to serve as a front-end for data acquisition and industrial control applications. This chapter describes how to configure the various communication functions supported by the Linux operating system.

The following topics are covered in this chapter:

- **Renaming the Network Interfaces**
- **Changing the Network Settings**
 - Editing the Interfaces Configuration File
 - Adjusting IP Addresses with "ifconfig"
- **DNS Client**
 - /etc/hostname
 - /etc/resolv.conf
 - /etc/nsswitch.conf
- **Configuring Ethernet Bonding**
- **Apache Web Server**
 - Install the apache web server
 - Default Homepage
- **IPTABLES**
 - IPTABLES Hierarchy
 - iptables Modules
 - Observe and Erase Chain Rules
 - Define Policy for Chain Rules
 - Append or Delete Rules
- **NAT (Network Address Translation)**
 - NAT Example
 - Enabling NAT at Bootup
- **PPP (Point-to-Point Protocol)**
 - Connecting to a PPP Server over a Simple Dial-up Connection
 - Connecting to a PPP Server over a Hard-wired Link
 - Checking the Connection
 - Setting up a Machine for Incoming PPP Connections
- **PPPoE**
- **NFS (Network File System) Client**
- **SNMP (Simple Network Management Protocol)**
- **OpenVPN**
 - Install the openvpn
 - Ethernet Bridging for Private Networks on Different Subnets
 - Ethernet Bridging for Private Networks on the Same Subnet
- **Routed IP**

Renaming the Network Interfaces

You can use the **udevd** command on Linux-based systems to detect new network interfaces, including Ethernet and wireless interfaces. The default order of the network interfaces is not the same as the order of the interfaces as labelled on the product. The udev rule, **/etc/udev/rules.d/01-rename_net_interface.rules**, can be used to reorder the network interface. The content of the file is similar to the following example:

```
KERNEL=="eth*", KERNELS=="0000:01:00.0", NAME="eth0"
KERNEL=="eth*", KERNELS=="0000:02:00.0", NAME="eth1"
KERNEL=="eth*", KERNELS=="0000:06:00.0", NAME="eth2"
KERNEL=="eth*", KERNELS=="0000:07:00.0", NAME="eth3"
```

Changing the Network Settings

The DA-720-LX computer has four 10/100/1000 Ethernet ports. The default IP addresses and netmasks of these network interfaces are:

	Default IP Address	Netmask
LAN1	192.168.3.127	255.255.255.0
LAN2	192.168.4.127	255.255.255.0
LAN3	192.168.5.127	255.255.255.0
LAN4	192.168.6.127	255.255.255.0
LAN5	192.168.7.127	255.255.255.0
LAN6	192.168.8.127	255.255.255.0
LAN7	192.168.9.127	255.255.255.0
LAN8	192.168.10.127	255.255.255.0
LAN9	192.168.11.127	255.255.255.0
LAN10	192.168.12.127	255.255.255.0
LAN11	192.168.13.127	255.255.255.0
LAN12	192.168.14.127	255.255.255.0
LAN13	192.168.15.127	255.255.255.0
LAN14	192.168.16.127	255.255.255.0

These network settings can be modified by editing the parameters in the **interfaces** configuration file. You can also temporarily adjust these setting using the **ifconfig** command.

Editing the Interfaces Configuration File

1. Type **cd /etc/network** to change the path to **network** folder.

```
Moxa:~# cd /etc/network
```

2. Type **vi interfaces** to edit the network configuration file using the **vi** editor.

You can then modify the network parameter in the **interfaces** file.

```
Moxa:/etc/network# vi interfaces
```

For example, you can configure the DA-720-LX's Ethernet ports for static or dynamic (DHCP) IP addresses.

Configuring a Static IP Address

The default static IP addresses can be modified as shown in the following example:

```
# The loopback network interface
auto lo
iface lo inet loopback

# The primary network interface
auto eth0
iface eth0 inet static
    address 192.168.3.127
    netmask 255.255.255.0
    broadcast 192.168.3.255

auto eth1
iface eth1 inet static
    address 192.168.4.127
    netmask 255.255.255.0
    broadcast 192.168.4.255

auto eth2
iface eth2 inet static
    address 192.168.5.127
    netmask 255.255.255.0
    broadcast 192.168.5.255

auto eth3
iface eth3 inet static
    address 192.168.6.127
    netmask 255.255.255.0
    broadcast 192.168.6.255

auto eth4
iface eth4 inet static
    address 192.168.7.127
    netmask 255.255.255.0
    broadcast 192.168.7.255

auto eth5
iface eth5 inet static
    address 192.168.8.127
    netmask 255.255.255.0
    broadcast 192.168.8.255

auto eth6
iface eth6 inet static
    address 192.168.9.127
    netmask 255.255.255.0
    broadcast 192.168.9.255

auto eth7
iface eth7 inet static
    address 192.168.10.127
```

```
netmask 255.255.255.0
broadcast 192.168.10.255

auto eth8
iface eth8 inet static
    address 192.168.11.127
    netmask 255.255.255.0
    broadcast 192.168.11.255

auto eth9
iface eth9 inet static
    address 192.168.12.127
    netmask 255.255.255.0
    broadcast 192.168.12.255

auto eth10
iface eth10 inet static
    address 192.168.13.127
    netmask 255.255.255.0
    broadcast 192.168.13.255

auto eth11
iface eth11 inet static
    address 192.168.14.127
    netmask 255.255.255.0
    broadcast 192.168.14.255

auto eth12
iface eth12 inet static
    address 192.168.15.127
    netmask 255.255.255.0
    broadcast 192.168.15.255

auto eth13
iface eth13 inet static
    address 192.168.16.127
    netmask 255.255.255.0
    broadcast 192.168.16.255
```

Configuring Dynamic IP Address Using DHCP

To configure one or both LAN ports to request an IP address dynamically, replace **static** with **dhcp** and then delete the rest of the lines.

```
# The primary network interface
auto eth0
iface eth0 inet dhcp
```

After modifying the boot settings of the LAN interface, issue the following command to activate the LAN settings:

```
Moxa:~# /etc/init.d/networking restart
```

Adjusting IP Addresses with "ifconfig"

IP settings can be adjusted during run-time, but the new settings will not be saved to the disk without modifying the file **/etc/network/interfaces**. For example, type the # **ifconfig eth0 192.168.1.1** command to change the IP address of LAN1 to 192.168.1.1.

```
Moxa:~# ifconfig eth0 192.168.1.1  
Moxa:~#
```

DNS Client

The DA-720-LX supports DNS client (but not DNS server). To set up DNS client, you need to edit three configuration files: **/etc/hostname**, **/etc/resolv.conf**, and **/etc/nsswitch.conf**.

/etc/hostname

1. Edit /etc/hostname:

```
moxa@Moxa:~# sudo vi /etc/hostname  
MOXA
```

2. Re-configure the hostname.

```
moxa@Moxa:~# sudo /etc/init.d/hostname.sh start
```

3. Check the new hostname.

```
moxa@Moxa:~# hostname
```

/etc/resolv.conf

This is the most important file that you need to edit when using DNS. For example, before using **# ntpdate time.stdtime.gov.tw** to update the system time, you will need to add the DNS server address to the file. Ask your network administrator which DNS server address you should use. The DNS server's IP address is specified using the **nameserver** command. For example, add the line **nameserver 8.8.8.8** to the **/etc/resolv.conf** file (assuming the DNS server's IP address is 8.8.8.8) as shown below:

```
Moxa:/etc# cat resolv.conf  
#  
# resolv.conf This file is the resolver configuration file  
# See resolver(5).  
#  
#nameserver 192.168.1.16  
nameserver 8.8.8.8  
nameserver 8.8.4.4  
nameserver 8.8.8.8  
Moxa:/etc#
```

/etc/nsswitch.conf

This file defines the sequence of files, `/etc/hosts` or `/etc/resolv.conf`, to be read to resolve the IP address. The `hosts` line in `/etc/nsswitch.conf` file here specifies that the `/etc/host` file and the DNS service should be used first to resolve the IP address.

```
# /etc/nsswitch.conf
#
# Example configuration of GNU Name Service Switch functionality.
# If you have the `glibc-doc-reference` and `info` packages installed, try:
# `info libc "Name Service Switch"` for information about this file.

passwd:      compat
group:       compat
shadow:      compat

hosts:        files dns
networks:    files

protocols:   db files
services:    db files
ethers:      db files
rpc:         db files

netgroup:    nis
```

Configuring Ethernet Bonding

The Linux bonding driver provides a method for aggregating multiple network interfaces into a single logical "bonded" interface. To use the bonding feature, you have to load the bonding driver with mode setting. Then use the `ifenslave` command to add the Ethernet interface to the `bond0` interface. A script that bonds `eth1` and `eth2` is given below. You can include this in the `/etc/init.d/bonding.sh` file.

```
#!/bin/bash

##### BEGIN INIT INFO
# Provides:          bonding
# Short-Description: Start the bonding service, bond eth1 and eth2.
# Required-Start:    $all
# Required-Stop:     $all
# Should-Start:
# Should-Stop:
# Default-Start:    2 3 4 5
# Default-Stop:      0 1 6
##### END INIT INFO

NAME=bonding
PATH=/bin:/usr/bin:/sbin:/usr/sbin

case "$1" in
  start)
    # to set ethX interfaces as slave the bond0 must have an ip
    if [ "$2" == "" ]; then
```

```

$0
exit 1
fi
echo "Starting bonding service: $NAME."
modprobe bonding mode=1 miimon=100      # load bonding module

ifdown eth2                      # putting down eth2
ifdown eth1                      # putting down eth1

ifconfig bond0 hw ether 00:90:E8:00:00:60    # change mac address
ifconfig bond0 $2 netmask 255.255.255.0 up  # set ip address

ifenslave bond0 eth2            # set eth2 in slave for bond0
ifenslave bond0 eth1            # set eth1 in slave for bond0
;;

stop)
echo "Stopping bonding service: $NAME"
ifenslave -d bond0 eth2          # release eth2 from bond0
ifenslave -d bond0 eth1          # release eth1 from bond0

ifconfig bond0 down             # putting down bond0
modprobe -r bonding             # unload bonding module

ifup eth2
ifup eth1
;;

restart)
$0 stop
$0 start $2
;;

*)
echo "Usage: /etc/init.d/$NAME {start|stop|restart} [ip address]"
exit 1
;;
esac

exit 0

```

You can add this script to the run level as follows:

```
moxa@Moxa:~# sudo insserv -v -d bonding.sh
```

To remove it from the run level, use the following command:

```
moxa@Moxa:~# sudo insserv -r bonding.sh
```

Apache Web Server

Install the apache web server

The Apache web server is one of the famous web server. It's has installed in this system but not enabled. You can enable it using the `sudo systemctl enable apache2` command.

```
Moxa:~# sudo systemctl enable apache2
```

Manually start the apache2 server.

```
Moxa:~# sudo systemctl start apache2
```

Default Homepage

The Apache web server's main configuration file is `/etc/apache2/sites-enabled/000-default.conf`, with the default homepage located at `/var/www/html/index.html`.

Save your own homepage to the following directory:

/var/www

Save your CGI page to the following directory:

/var/www

Before you modify the homepage, use a browser (such as Microsoft Internet Explorer or Mozilla Firefox) from your PC to test if the Apache web server is working. Type the LAN1 IP address in the browser's address box to open the homepage. For example, if the default IP address 192.168.3.127 is still active, type:

http://192.168.3.127/

To test the default CGI page, type:

http://192.168.3.127/cgi-bin/w3mmail.cgi

IPTABLES

IPTABLES is an administrative tool for setting up, maintaining, and inspecting the Linux kernel's IP packet filter rule tables. Several different tables are defined, with each table containing built-in chains and user-defined chains.

Each chain is a list of rules that apply to a certain type of packet. Each rule specifies what to do with a matching packet. A rule (such as a jump to a user-defined chain in the same table) is called a **target**.

The DA-720-LX supports three types of IPTABLES: Filter tables, NAT tables, and Mangle tables.

Filter Table

Includes the following chains:

- **INPUT chain**
- **OUTPUT chain**
- **FORWARD chain**

NAT Table

Includes the following chains:

- **PREROUTING chain**—transfers the destination IP address (DNAT).
- **POSTROUTING chain**—works after the routing process and before the Ethernet device process to transfer the source IP address (SNAT).
- **OUTPUT chain**—produces local packets.

Sub-Tables

- **Source NAT (SNAT)**—changes the first source IP address of the packet.
- **Destination NAT (DNAT)**—changes the first destination IP address of the packet.
- **MASQUERADE**—a special form for SNAT. If one host can connect to the Internet, then the other computers that connect to this host can connect to the Internet when the computer does not have an actual IP address.
- **REDIRECT**—a special form of DNAT that re-sends packets to a local host independent of the destination IP address.


Mangle Table

- **PREROUTING chain**—pre-processes packets before the routing process.
- **OUTPUT chain**—processes packets after the routing process.

Mangle tables can have one of three extensions—TTL, MARK, TOS.

IPTABLES Hierarchy

The following figure shows the IPTABLES hierarchy:



iptables Modules

The iptables supports the following sub-modules. Be sure to use the module that matches your application.

arptable_filter.ko	arp_tables.ko	arpt_mangle.ko	ip_conntrack_amanda.ko
ip_conntrack_ftp.ko	ip_conntrack_h323.ko	ip_conntrack_irc.ko	ip_conntrack.ko
ip_conntrack_netbios_ns.ko	ip_conntrack_netlink.ko	ip_conntrack_pptp.ko	ip_conntrack_proto_sctp.ko
ip_conntrack_sip.ko	ip_conntrack_tftp.ko	ip_nat_amanda.ko	ip_nat_ftp.ko
ip_nat_h323.ko	ip_nat_irc.ko	ip_nat.ko	ip_nat_pptp.ko
ip_nat_sip.ko	ip_nat_snmp_basic.ko	ip_nat_tftp.ko	ip_queue.ko
iptable_filter.ko	iptable_mangle.ko	iptable_nat.ko	iptable_raw.ko
ip_tables.ko	ipt_addrtype.ko	ipt_ah.ko	ipt_CLUSTERIP.ko
ipt_dscp.ko	ipt_DSCP.ko	ipt_ecn.ko	ipt_ECN.ko
ipt_hashlimit.ko	ipt_iprange.ko	ipt_LOG.ko	ipt_MASQUERADE.ko
ipt_NETMAP.ko	ipt_owner.ko	ipt_recent.ko	ipt_REDIRECT.ko
ipt_REJECT.ko	ipt_SAME.ko	ipt_TCPMSS.ko	ipt_tos.ko
ipt_TOS.ko	ipt_ttl.ko	ipt_TTL.ko	ipt_ULOG.ko

The basic syntax to enable and load an **iptables** module is as follows:

```
# lsmod
# modprobe ip_tables
# modprobe iptable_filter
# modprobe iptable_mangle
# modprobe iptable_nat
```

Use **lsmod** to check if the **ip_tables** module has already been loaded in the DA-720-LX. Use **modprobe** to insert and enable the module.

Use **iptables**, **iptables-restore**, and **iptables-save** to maintain the database.



ATTENTION

The **iptables** module can be used in packet filtering or network address translation. Be careful when setting up the **iptables** rules. If the rules are incorrect, remote hosts that connect via a LAN or PPP may be denied access. We recommend using the VGA console to set up the **iptables** module. Click on the following links for more information:

<http://www.linuxguruz.com/iptables/>
<http://www.netfilter.org/documentation/HOWTO//packet-filtering-HOWTO.html>

Since the **iptables** command are complex, we have divided our discussion of the various rules into three categories: **Observe and erase chain rules**, **Define policy rules**, and **Append or delete rules**.

Observe and Erase Chain Rules

Usage

```
# iptables [-t tables] [-L] [-n]
-t tables: Table to manipulate (default: 'filter'); example: nat or filter.
-L [chain]: List List all rules in selected chains. If no chain is selected, all chains are listed.
-n: Numeric output of addresses and ports.

# iptables [-t tables] [-FXZ]
-F: Flush the selected chain (all the chains in the table if none is listed).
-X: Delete the specified user-defined chain.
-Z: Set the packet and byte counters in all chains to zero.
```

Example

```
# iptables -L -n
```

In this example, since we do not use the **-t** parameter, the system uses the default "filter" table. Three chains are included: INPUT, OUTPUT, and FORWARD. INPUT chains are accepted automatically, and all connections are accepted without being filtered.

```
# iptables -F
# iptables -X
# iptables -Z
```

Define Policy for Chain Rules

Usage

```
# iptables [-t tables] [-P] [INPUT, OUTPUT, FORWARD, PREROUTING, OUTPUT, POSTROUTING]
[ACCEPT, DROP]

-P: Set the policy for the chain to the given target.
INPUT: For packets coming into the DA-720-LX.
OUTPUT: For locally-generated packets.
FORWARD: For packets routed out through the DA-720-LX.
PREROUTING: To alter packets as soon as they come in.
POSTROUTING: To alter packets as they are about to be sent out.
```

Example

```
#iptables -P INPUT DROP
#iptables -P OUTPUT ACCEPT
#iptables -P FORWARD ACCEPT
#iptables -t nat -P PREROUTING ACCEPT
#iptables -t nat -P OUTPUT ACCEPT
#iptables -t nat -P POSTROUTING ACCEPT
```

In this example, the policy accepts outgoing packets and denies incoming packets.

Append or Delete Rules

Usage

```
# iptables [-t table] [-AI] [INPUT, OUTPUT, FORWARD] [-io interface] [-p tcp, udp, icmp, all] [-s
IP/network] [--sport ports] [-d IP/network] [--dport ports] -j [ACCEPT, DROP]

-A: Append one or more rules to the end of the selected chain.
-I: Insert one or more rules in the selected chain as the given rule number.
-i: Name of an interface via which a packet is going to be received.
-o: Name of an interface via which a packet is going to be sent.
-p: The protocol of the rule or of the packet to check.
-s: Source address (network name, host name, network IP address, or plain IP address).
--sport: Source port number.
-d: Destination address.
--dport: Destination port number.
-j: Jump target. Specifies the target of the rules; i.e., how to handle matched packets.
```

For example, ACCEPT the packet, DROP the packet, or LOG the packet.

Examples

Example 1: Accept all packets from the lo interface.

```
# iptables -A INPUT -i lo -j ACCEPT
```

Example 2: Accept TCP packets from 192.168.0.1.

```
# iptables -A INPUT -i eth0 -p tcp -s 192.168.0.1 -j ACCEPT
```

Example 3: Accept TCP packets from Class C network 192.168.1.0/24.

```
# iptables -A INPUT -i eth0 -p tcp -s 192.168.1.0/24 -j ACCEPT
```

Example 4: Drop TCP packets from 192.168.1.25.

```
# iptables -A INPUT -i eth0 -p tcp -s 192.168.1.25 -j DROP
```

Example 5: Drop TCP packets addressed for port 21.

```
# iptables -A INPUT -i eth0 -p tcp --dport 21 -j DROP
```

Example 6: Accept TCP packets from 192.168.0.24 to DA-720-LX's port 137, 138, 139

```
# iptables -A INPUT -i eth0 -p tcp -s 192.168.0.24 --dport 137:139 -j ACCEPT
```

Example 7: Log TCP packets that visit DA-720-LX's port 25.

```
# iptables -A INPUT -i eth0 -p tcp --dport 25 -j LOG
```

Example 8: Drop all packets from MAC address 01:02:03:04:05:06.

```
# iptables -A INPUT -i eth0 -p all -m mac --mac-source 01:02:03:04:05:06 -j DROP
```



ATTENTION

In Example 8, first run the **# modprobe ipt_mac** command to load the ipt_mac module.

NAT (Network Address Translation)

The NAT (Network Address Translation) protocol translates IP addresses used on one network into IP addresses used on a connecting network. One network is designated the inside network and the other is the outside network. Typically, the DA-720-LX connects several devices on a network and maps local inside network addresses to one or more global outside IP addresses, and un-maps the global IP addresses on incoming packets back into local IP addresses.



ATTENTION

Click the following link for more information on NAT:


<http://www.netfilter.org/documentation/HOWTO//packet-filtering-HOWTO.html>

NAT Example

The IP address of all packets leaving LAN1 are changed to **192.168.3.127**

NOTE The **ipt_MASQUERADE** module is required for the NAT function.

(*):*



Enabling NAT at Bootup

In most real world situations, you will want to use a simple shell script to enable NAT when the DA-720-LX boots up. The following script is an example.

```
#!/bin/bash
# If you put this shell script in the /home/nat.sh
# Remember to chmod 744 /home/nat.sh
# Edit the rc.local file to make this shell startup automatically.
# vi /etc/rc.local
# Add a line in the end of rc.local /home/nat.sh
EXIF= "eth0" #This is an external interface for setting up a valid IP address.
EXNET= "192.168.4.0/24" #This is an internal network address.
# Step 1. Insert modules.
# Here 2> /dev/null means the standard error messages will be dump to null device.
modprobe ip_tables 2> /dev/null
modprobe ip_nat_ftp 2> /dev/null
modprobe ip_nat_irc 2> /dev/null
modprobe ip_conntrack 2> /dev/null
modprobe ip_conntrack_ftp 2> /dev/null
modprobe ip_conntrack_irc 2> /dev/null
# Step 2. Define variables, enable routing and erase default rules.
PATH=/bin:/sbin:/usr/bin:/usr/sbin:/usr/local/bin:/usr/local/sbin
export PATH
echo "1" > /proc/sys/net/ipv4/ip_forward
/sbin/iptables -F
/sbin/iptables -X
/sbin/iptables -Z
/sbin/iptables -F -t nat
/sbin/iptables -X -t nat
/sbin/iptables -Z -t nat
/sbin/iptables -P INPUT ACCEPT
/sbin/iptables -P OUTPUT ACCEPT
/sbin/iptables -P FORWARD ACCEPT
/sbin/iptables -t nat -P PREROUTING ACCEPT
/sbin/iptables -t nat -P POSTROUTING ACCEPT
/sbin/iptables -t nat -P OUTPUT ACCEPT
# Step 3. Enable IP masquerade.
```

```
#echo 1 > /proc/sys/net/ipv4/ip_forward#modprobe ipt_MASQUERADE#iptables -t nat -A POSTROUTING -o eth0 -j MASQUERADE
```

PPP (Point-to-Point Protocol)

PPP is used to run IP (Internet Protocol) and other network protocols over a serial link. PPP can be used for direct serial connections (using a null-modem cable) over a Telnet link, and links established using a modem over a telephone line.

Modem/PPP access is almost identical to connecting directly to a network through the embedded computer Ethernet port. Since PPP is a peer-to-peer system, the Linux operating system can use it to link two networks (or a local network to the Internet) to create a Wide Area Network (WAN).

ATTENTION



Click on the following links for more information about PPP:

<http://tldp.org/HOWTO/PPP-HOWTO/index.html>
<http://axion.physics.ubc.ca/ppp-linux.html>

Connecting to a PPP Server over a Simple Dial-up Connection

The **pppd** command is used to connect to a PPP server by modem. Use this command for old PPP servers that prompt for a login name (replace “username” with the correct name) and password (replace “password” with the correct password). The **debug crtscs** and **defaultroute 192.1.1.17** parameters are optional.

```
#pppd connect 'chat -v "" ATDT5551212 CONNECT ""login: username password: password' /dev/ ttyS0 115200 debug crtscs modem defaultroute 192.1.1.17
```

If the PPP server does not prompt for the username and password, the **pppd** command should be entered as follows (replace “username” with the correct username and replace “password” with the correct password):

```
#pppd connect 'chat -v "" ATDT5551212 CONNECT ""\ user username password password /dev/ ttyS0 115200 crtscs modem
```

The **pppd** command options are described below:

Option	Description
connect 'chat etc...'	This option gives the command to contact the PPP server. The chat program is used to dial a remote computer. The entire command is enclosed in single quotes because pppd expects a one-word argument for the connect option. The options for chat are given below:
-v	verbose mode; log what we do to syslog
" "	Double quotes—don't wait for a prompt, but instead do ... (note that you must include a space after the second quotation mark)
ATDT5551212	Dial the modem, and then ...
CONNECT	Wait for an answer.
" "	Send a return (null text followed by the usual return)
Login: username; password: password	Log in with username and password.
Note: For more information about the chat utility, refer to the chat man page.	
/dev/	Specify the callout serial port.
115200	The baud rate.
debug	Log status in syslog.
crtscts	Use hardware flow control between the computer and modem (mandatory at baudrates of 115200 and above).
modem	Indicates that this is a modem device; pppd will hang up the phone before and after making the call.
defaultroute	Once the PPP link is established, make it the default route; if you have a PPP link to the Internet, this is probably what you want.
192.1.1.17	This is a degenerate case of a general option of the form x.x.x.x:y.y.y.y. Here x.x.x.x is the local IP address and y.y.y.y is the IP address of the remote end of the PPP connection. If this option is not specified, or if just one side is specified, then x.x.x.x defaults to the IP address associated with the local machine's hostname (located in /etc/hosts), and y.y.y.y is determined by the remote machine.

Connecting to a PPP Server over a Hard-wired Link

If a username and password are not required, use the following command (note that **noipdefault** is optional):

```
#pppd connect 'chat -v" " " ' noipdefault /dev/ttys0 19200 crtscts
```

If a username and password is required, use the following command (note that **noipdefault** is optional, and the username and password are both "root"):

```
#pppd connect 'chat -v" " " ' user root password root noipdefault /dev/ttys0 19200 crtscts
```

Checking the Connection

Once you have set up a PPP connection, there are some steps you can take to test the connection. First, type:

```
# /sbin/ifconfig
```

Depending on your distribution, the command might be located elsewhere. After executing the command, you should be able to see all of the network interfaces that are up. The **ppp0** interface is one of the network interfaces that is displayed. The first IP address shown is the IP address of the computer, and **P-t-P address** is the IP address of the server. The output should be similar to the following:

```
lo      Link encap Local Loopback
        inet addr 127.0.0.1   Bcast 127.255.255.255 Mask 255.0.0.0
              UP LOOPBACK RUNNING MTU 2000 Metric 1
              RX packets 0 errors 0 dropped 0 overrun 0

ppp0    Link encap Point-to-Point Protocol
        inet addr 192.76.32.3   P-t-P 129.67.1.165 Mask 255.255.255.0
              UP POINTOPOINT RUNNING MTU 1500 Metric 1
              RX packets 33 errors 0 dropped 0 overrun 0
              TX packets 42 errors 0 dropped 0 overrun 0
```

Now, type:

```
# ping z.z.z.z
```

Where z.z.z.z is the address of your name server. The output should be similar to the following:

```
Moxa:~# ping 129.67.1.165
PING 129.67.1.165 (129.67.1.165): 56 data bytes
64 bytes from 129.67.1.165: icmp_seq=0 ttl=225 time=268 ms
64 bytes from 129.67.1.165: icmp_seq=1 ttl=225 time=247 ms
64 bytes from 129.67.1.165: icmp_seq=2 ttl=225 time=266 ms
^C
--- 129.67.1.165 ping statistics ---
3 packets transmitted, 3 packets received, 0% packet loss
round-trip min/avg/max = 247/260/268 ms
Moxa:~#
```

Try typing:

```
# netstat -nr
```

You should see three routes similar to the following:

```
Kernel routing table
Destination     Gateway     Genmask       Flags   Metric   Ref Use
iface
129.67.1.165   0.0.0.0    255.255.255.255 UH        0        0    6
ppp0
127.0.0.0      0.0.0.0    255.0.0.0     U         0        0    lo
0.0.0.0         129.67.1.165 0.0.0.0      UG        0        0   6298
ppp0
```

If your output looks similar but does not have the "destination 0.0.0.0" line (which refers to the default route used for connections), you may have run pppd without the **defaultroute** option. At this point, you can try using Telnet, FTP, or Finger services, bearing in mind that you will have to use numeric IP addresses unless you have configured **/etc/resolv.conf** correctly.

Setting up a Machine for Incoming PPP Connections

Method 1: pppd dial-in with pppd commands

This first example applies to using a modem, and requiring authorization with a username and password.

```
#pppd /dev/ttys0 115200 crtscts modem 192.168.16.1:192.168.16.2 login auth
```

You should also add the following line to the file **/etc/ppp/pap-secrets**:

```
* * " " *
```

The first star (*) lets everyone login. The second star (*) lets every host connect. The pair of double quotation marks ("") indicates that the file **/etc/passwd** can be used to check the password. The last star (*) is to let any IP connect.

The following example does not check the username and password:

```
# pppd/dev/ttys0 115200 crtscts modem 192.168.16.1:192.168.16.2
```

Method 2: pppd dial-in with pppd script

Configure a dial-in script **/etc/ppp/peer/dialin**

```
# You usually need this if there is no PAP authentication
noauth
#auth
#login

# The chat script (be sure to edit that file, too!)
init "/usr/sbin/chat -v -f /etc/ppp/ppp-ttys0.chat"

# Set up routing to go through this PPP link
defaultroute

# Default modem (you better replace this with /dev/ttysx!)
/dev/ttys0

# Speed
115200

# Keep modem up even if connection fails
persist
crtscts
modem
192.168.16.1:192.168.16.2
debug
-detach
```

Configure the chat script **/etc/ppp/ppp-ttys0.chat**

```
SAY      'Auto Answer ON\n'
``      ATS0=1
```

Start the **pppd** dial-in service.

```
# pppd call dialin
```

ATTENTION

If you would like to have auto dial-in service, you can launch the dial-in service in **/etc/inittab** with the **respawn** command.

```
Moxa:~# mount -o remount,rw /dev/sda1 /
Moxa:~# echo "p0:2345:respawn:pppd call dialin" >> /etc/inittab
Moxa:~# umount /
```

PPPoE

Use the following procedure to configure PPPoE:

1. Connect the DA-720-LX's LAN port to an ADSL modem with a cross-over cable, HUB, or switch.
2. Log in to the DA-720-LX as the root user.

Edit the file **/etc/ppp/chap-secrets** and add the following:

```
"username@hinet.net" * "password" *
```

```
# Secrets for authentication using CHAP
# client      server      secret          IP addresses

# PPPOE example, if you want to use it, you need to unmark it and modify it
"username@hinet.net" * "password" *
```

username@hinet.net is the username obtained from the ISP to log in to the ISP account and the **password** is the corresponding password for the account.

Edit the file **/etc/ppp/pap-secrets** and add the following:

```
"username@hinet.net" * "password" *
```

```
# ATTENTION: The definitions here can allow users to login without a
# password if you don't use the login option of pppd! The mgetty Debian
# package already provides this option; make sure you don't change that.

# INBOUND connections

# Every regular user can use PPP and has to use passwords from /etc/passwd
*      hostname      ""      *
"username@hinet.net" *      "password"      *

# UserIDs that cannot use PPP at all. Check your /etc/passwd and add any
# other accounts that should not be able to use pppd!
guest  hostname      "*"      -
master  hostname      "*"      -
root    hostname      "*"      -
support hostname      "*"      -
stats   hostname      "*"      -

# OUTBOUND connections
```

username@hinet.net is the username obtained from the ISP to log in to the ISP account; **password** is the corresponding password for the account.

Edit the file **/etc/ppp/options** and add the following line:

```
plugin rp-pppoe
```

```

# received. Note: it is not advisable to use this option with the persist
# option without the demand option. If the active-filter option is given,
# data packets which are rejected by the specified activity filter also
# count as the link being idle.
#idle <n>

# Specifies how many seconds to wait before re-initiating the link after
# it terminates. This option only has any effect if the persist or demand
# option is used. The holdoff period is not applied if the link was
# terminated because it was idle.
#holdoff <n>

# Wait for up n milliseconds after the connect script finishes for a valid
# PPP packet from the peer. At the end of this time, or when a valid PPP
# packet is received from the peer, pppd will commence negotiation by
# sending its first LCP packet. The default value is 1000 (1 second).
# This wait period only applies if the connect or pty option is used.
#connect-delay <n>

# Load the pppoe plugin
plugin rp-pppoe.so

# ---<End of File>---

```

3. If you use LAN1 to connect to the ADSL modem, add the file **/etc/ppp/options.eth0**, if you use LAN2 to connect to the ADSL modem, add **/etc/ppp/options.eth1**, etc.

```

name username@hinet.net
mtu 1492
mru 1492
defaultroute
noipdefault
~
~
"/etc/ppp/options.eth0" 5 lines, 67 characters

```

Type your username (the one you set in the **/etc/ppp/pap-secrets** and **/etc/ppp/chap-secrets** files) after the **name** option. You may add other options as needed.

4. Set up DNS.

If you are using DNS servers supplied by your ISP, edit the file **/etc/resolv.conf** by adding the following lines of code:

```

nameserver ip_addr_of_first_dns_server
nameserver ip_addr_of_second_dns_server

```

For example:

```

nameserver 8.8.8.8
nameserver 8.8.4.4

```

```

Moxa:/etc# cat resolv.conf
#
# resolv.conf  This file is the resolver configuration file
# See resolver(5).
#
nameserver 8.8.8.8
nameserver 8.8.4.4
Moxa:/etc#

```

Use the following command to create a **PPoE** connection:

```
#pppd eth0
```

5. The ADSL modem is connected to the **LAN1** port, which is named **eth0**. If the ADSL modem is connected to **LAN2**, use **eth1**, etc.
6. Type **#ifconfig ppp0** to check if the connection is OK. If the connection is OK, you should see the IP address of ppp0. Use **#ping** to test the IP address.

```
ppp0      Link encap Point-to-Point Protocol
          inet addr 192.76.32.3   P-t-P 129.67.1.165 Mask 255.255.255.0
          UP POINTOPOINT RUNNING MTU 1500 Metric 1
          RX packets 33 errors 0 dropped 0 overrun 0
          TX packets 42 errors 0 dropped 0 overrun 0
```

7. If you want to disconnect the connection, use the **kill** command to stop the **pppd** process.

NFS (Network File System) Client

The Network File System (NFS) is used to mount a disk partition on a remote machine (as if it were on a local hard drive), allowing fast, and seamless sharing of files across a network. NFS allows you to develop applications for the DA-720-LX without worrying about the amount of disk space that will be available. The DA-720-LX only supports NFS client protocol.

ATTENTION



Click on the following links for more information about NFS:

<http://www.ietf.org/rfc/rfc1213.txt>

<http://www.faqs.org/rfcs/rfc1317.html>

The following procedures illustrate how to mount a remote NFS Server:

1. Scan the NFS Server's shared directory:

```
#showmount -e HOST
```

showmount: Shows the mount information of an NFS Server

-e: Shows the NFS Server's export list.

HOST: IP address or DNS address

2. Establish a mount point on the NFS Client site:

```
#mkdir -p /home/nfs/public
```

3. Mount the remote directory to a local directory:

```
# mount -t nfs -o nolock 192.168.3.100:/home/public /home/nfs/public
```

(This is where 192.168.3.100 is the example IP address of the NFS server.)

SNMP (Simple Network Management Protocol)

The DA-720-LX comes with the SNMP v2c (Simple Network Management Protocol) software package. The `snmpd` service is disabled by default. You can use the following command to enable it:

```
moxa@Moxa:~# sudo systemctl enable snmpd
```

The `snmpd` configuration is at `/etc/snmp/snmpd.conf`. You can configure the `snmpd` listening address and port only from the local system to all interfaces.

```
# /etc/snmp/snmpd.conf
#
# ...
# Listen for connections from the local system only
#agentAddress udp:127.0.0.1:161
# Listen for connections on all interfaces (both IPv4 *and* IPv6)
agentAddress udp:161,udp6:[::1]:161
```

Then restart the `snmpd` service.

```
moxa@Moxa:~# sudo systemctl restart snmpd
```

The following example shows an SNMP agent responding to a query from the SNMP browser on the host site:

```
iso.3.6.1.2.1.1.1.0 = STRING: "Linux Moxa 4.6.0-0.bpo.1-amd64 #1 SMP Debian
4.6.4-1~bpo8+1 (2016-08-11) x86_64"
iso.3.6.1.2.1.1.2.0 = OID: iso.3.6.1.4.1.8691.12.720
iso.3.6.1.2.1.1.3.0 = Timeticks: (163) 0:00:01.63
iso.3.6.1.2.1.1.4.0 = STRING: "Moxa Inc., Embedded Computing Business.
<www.moxa.com>"
iso.3.6.1.2.1.1.5.0 = STRING: "Moxa"
iso.3.6.1.2.1.1.6.0 = STRING: "F1.4, No.135, Lane 235, Baoquao Rd., Xindian Dist.,
New Taipei City, Taiwan, R.O.C."
iso.3.6.1.2.1.1.7.0 = INTEGER: 72
iso.3.6.1.2.1.1.8.0 = Timeticks: (4) 0:00:00.04
iso.3.6.1.2.1.1.9.1.2.1 = OID: iso.3.6.1.6.3.11.3.1.1
iso.3.6.1.2.1.1.9.1.2.2 = OID: iso.3.6.1.6.3.15.2.1.1
iso.3.6.1.2.1.1.9.1.2.3 = OID: iso.3.6.1.6.3.10.3.1.1
iso.3.6.1.2.1.1.9.1.2.4 = OID: iso.3.6.1.6.3.1
iso.3.6.1.2.1.1.9.1.2.5 = OID: iso.3.6.1.2.1.49
iso.3.6.1.2.1.1.9.1.2.6 = OID: iso.3.6.1.2.1.4
iso.3.6.1.2.1.1.9.1.2.7 = OID: iso.3.6.1.2.1.50
iso.3.6.1.2.1.1.9.1.2.8 = OID: iso.3.6.1.6.3.16.2.2.1
iso.3.6.1.2.1.1.9.1.2.9 = OID: iso.3.6.1.6.3.13.3.1.3
iso.3.6.1.2.1.1.9.1.2.10 = OID: iso.3.6.1.2.1.92
iso.3.6.1.2.1.1.9.1.3.1 = STRING: "The MIB for Message Processing and Dispatching."
iso.3.6.1.2.1.1.9.1.3.2 = STRING: "The management information definitions for the
SNMP User-based Security Model."
iso.3.6.1.2.1.1.9.1.3.3 = STRING: "The SNMP Management Architecture MIB."
iso.3.6.1.2.1.1.9.1.3.4 = STRING: "The MIB module for SNMPv2 entities"
iso.3.6.1.2.1.1.9.1.3.5 = STRING: "The MIB module for managing TCP implementations"
iso.3.6.1.2.1.1.9.1.3.6 = STRING: "The MIB module for managing IP and ICMP
implementations"
iso.3.6.1.2.1.1.9.1.3.7 = STRING: "The MIB module for managing UDP implementations"
iso.3.6.1.2.1.1.9.1.3.8 = STRING: "View-based Access Control Model for SNMP."
iso.3.6.1.2.1.1.9.1.3.9 = STRING: "The MIB modules for managing SNMP Notification,"
```

```

plus filtering."
iso.3.6.1.2.1.1.9.1.3.10 = STRING: "The MIB module for logging SNMP Notifications."
iso.3.6.1.2.1.1.9.1.4.1 = Timeticks: (4) 0:00:00.04
iso.3.6.1.2.1.1.9.1.4.2 = Timeticks: (4) 0:00:00.04
iso.3.6.1.2.1.1.9.1.4.3 = Timeticks: (4) 0:00:00.04
iso.3.6.1.2.1.1.9.1.4.4 = Timeticks: (4) 0:00:00.04
iso.3.6.1.2.1.1.9.1.4.5 = Timeticks: (4) 0:00:00.04
iso.3.6.1.2.1.1.9.1.4.6 = Timeticks: (4) 0:00:00.04
iso.3.6.1.2.1.1.9.1.4.7 = Timeticks: (4) 0:00:00.04
iso.3.6.1.2.1.1.9.1.4.8 = Timeticks: (4) 0:00:00.04
iso.3.6.1.2.1.1.9.1.4.9 = Timeticks: (4) 0:00:00.04
iso.3.6.1.2.1.1.9.1.4.10 = Timeticks: (4) 0:00:00.04
iso.3.6.1.2.1.25.1.1.0 = Timeticks: (55237) 0:09:12.37
iso.3.6.1.2.1.25.1.2.0 = Hex-STRING: 07 E0 09 13 03 0B 2F 00 2D 04 00
iso.3.6.1.2.1.25.1.3.0 = INTEGER: 393216
iso.3.6.1.2.1.25.1.4.0 = STRING: "BOOT_IMAGE=/boot/vmlinuz-4.6.0-0.bpo.1-amd64
root=LABEL=root ro initrd=/install/initrd.gz quiet 8250.nr_uarts=2
"
iso.3.6.1.2.1.25.1.5.0 = Gauge32: 2
iso.3.6.1.2.1.25.1.6.0 = Gauge32: 24
iso.3.6.1.2.1.25.1.7.0 = INTEGER: 0
iso.3.6.1.2.1.25.1.7.0 = No more variables left in this MIB View (It is past the
end of the MIB tree)
...

```

To remove the moxa-snmp-da-720 package, use the following command:

```

moxa@Moxa:~$ sudo dpkg -r moxa-snmp-da-682a
(Reading database ... 31739 files and directories currently installed.)
Removing moxa-snmp-da-682a ...
Stopping Moxa SNMP ...
Stopping Moxa SNMP OK
update-rc.d: using dependency based boot sequencing

```

OpenVPN

Install the openvpn

OpenVPN is a community VPN software. You can install it by this command.

```

moxa@Moxa:~$ sudo apt-get install openvpn

```


OpenVPN provides two types of tunnels for implementing VPNs: **Routed IP Tunnels** and **Bridged Ethernet Tunnels**.

An Ethernet bridge is used to connect different Ethernet networks together. The Ethernets are bundled into one bigger, "logical" Ethernet. Each Ethernet corresponds to one physical interface (or port) that is connected to the bridge.

On each OpenVPN machine, you should carry out configurations in the **/etc/openvpn** directory, where script files and key files reside. Once established, all operations will be performed in that directory.

Ethernet Bridging for Private Networks on Different Subnets

- Set up four machines, as shown in the following diagram:



Host A represents the machine that belongs to OpenVPN A, and Host B represents the machine that belongs to OpenVPN B. The two remote subnets are configured for a different range of IP addresses. When this configuration is moved to a public network, the external interfaces of the OpenVPN machines should be configured for static IPs, or connected to another device (such as a firewall or DSL box) first.

- Generate a preset shared key by typing the following command:

```
# openvpn --genkey --secret secrouter.key
```

- Copy the file that is generated to the OpenVPN machine:

```
# scp /etc/openvpn/secrouter.key 192.168.8.174:/etc/openvpn
```

ATTENTION

 A pre-shared key is located in `/etc/openvpn/secrouter.key`. You can use it for testing purposes. We suggest creating a new key for commercial purposes.

- On machine OpenVPN A, modify the remote address in configuration file `/etc/openvpn/tap0-br.conf`.

```
# point to the peer
remote 192.168.8.174
dev tap0
port 1194
secret /etc/openvpn/secrouter.key
cipher DES-EDE3-CBC
auth MD5
tun-mtu 1500
tun-mtu-extra 64
ping 40
up /etc/openvpn/tap0-br.sh
#comp-lzo
```

- Next, modify the routing table in `/etc/openvpn/tap0-br.sh` script.

```
-----Start-----
#!/bin/sh
# value after "-net" is the subnet behind the remote peer
route add -net 192.168.4.0 netmask 255.255.255.0 dev br0
-----end-----
```

6. And then configure the bridge interface in **/etc/openvpn/bridge**.

```
#!/bin/bash
# Create global variables
# Define Bridge Interface
br="br0"
# Define list of TAP interfaces to be bridged,
# for example tap="tap0 tap1 tap2".
tap="tap0"
# Define physical ethernet interface to be bridged
# with TAP interface(s) above.
eth="eth1"
eth_ip="192.168.8.173"
eth_netmask="255.255.255.0"
eth_broadcast="192.168.8.255"
#gw="192.168.8.174"
...
```

7. Start the bridge script file to configure the bridge interface:

```
# /etc/openvpn/bridge restart
```

8. On machine OpenVPN B, modify the remote address in configuration file

```
/etc/openvpn/tap0-br.conf.
```

```
# point to the peer
remote 192.168.8.173
dev tap0
secret /etc/openvpn/secrouter.key
cipher DES-EDE3-CBC
auth MD5
tun-mtu 1500
tun-mtu-extra 64
ping 40
up /etc/openvpn/tap0-br.sh
#comp-lzo
```

9. Next modify the routing table in **/etc/openvpn/tap0-br.sh** script file.

```
-----Start-----
#!/bin/sh
# value after "-net" is the subnet behind the remote peer
route add -net 192.168.2.0 netmask 255.255.255.0 dev br0
----- end -----
```

10. Then configure the bridge interface in **/etc/openvpn/bridge**.

```
#!/bin/bash
# Create global variables
# Define Bridge Interface
br="br0"
# Define list of TAP interfaces to be bridged,
# for example tap="tap0 tap1 tap2".
tap="tap0"
# Define physical ethernet interface to be bridged
# with TAP interface(s) above.
eth="eth1"
eth_ip="192.168.8.174"
eth_netmask="255.255.255.0"
```

```
eth_broadcast="192.168.8.255"  
#gw="192.168.8.173"  
...
```

11. Start the bridge script file to configure the bridge interface.

```
# /etc/openvpn/bridge restart
```

ATTENTION



Select cipher and authentication algorithms by specifying cipher and auth. To see which algorithms are available, type:

```
# openvpn --show-ciphers  
# openvpn --show-auths
```

12. Start both OpenVPN peers on machine OpenVPN A and OpenVPN B.

```
# openvpn --config /etc/openvpn/tap0-br.conf&
```

If you see the line **Peer Connection Initiated with 192.168.8.173:5000** on each machine, the connection between OpenVPN machines has been established successfully on UDP port 5000.

ATTENTION



You can create link symbols to start the OpenVPN service at boot time:

```
# ln -sf /etc/init.d/openvpn /etc/rc2.d/S16openvpn
```

To stop the service, you should create these links:

```
# ln -sf /etc/init.d/openvpn /etc/rc0.d/K80openvpn  
# ln -sf /etc/init.d/openvpn /etc/rc6.d/K80openvpn
```

13. On each OpenVPN machine, check the routing table by typing the **# route** command

Destination	Gateway	Genmask	Flags	Metric	Ref	Use	Iface
192.168.5.0	0.0.0.0	255.255.255.255.0	U	0	0	0	eth2
192.168.4.0	0.0.0.0	255.255.255.255.0	U	0	0	0	br0
192.168.3.0	0.0.0.0	255.255.255.255.0	U	0	0	0	eth0
192.168.30.0	0.0.0.0	255.255.255.255.0	U	0	0	0	eth3
192.168.8.0	0.0.0.0	255.255.255.255.0	U	0	0	0	br0

Interface **eth1** and device **tap0** both connect to the bridging interface, and the virtual device **tun** sits on top of **tap0**. This ensures that all traffic coming to this bridge from internal networks connected to interface **eth1** write to the TAP/TUN device that the OpenVPN program monitors. Once the OpenVPN program detects traffic on the virtual device, it sends the traffic to its peer.

14. To create an indirect connection to Host B from Host A, you need to add the following routing item:

```
# route add -net 192.168.4.0 netmask 255.255.255.0 dev eth0
```

To create an indirect connection to Host A from Host B, you need to add the following routing item:

```
# route add -net 192.168.2.0 netmask 255.255.255.0 dev eth0
```

Now ping Host B from Host A by typing:

```
# ping 192.168.4.174
```


A successful **ping** command indicates that you have created a VPN system that only allows authorized users from one internal network to access users at the remote site. For this system, all data is transmitted by UDP packets on port 5000 between OpenVPN peers.

15. To shut down OpenVPN programs, type the command:

```
# killall -TERM openvpn
```

Ethernet Bridging for Private Networks on the Same Subnet

- Set up four machines, as shown in the following diagram:




- The configuration procedure is almost the same as for the previous example. The only difference is that you will need to comment out the parameter **up** in **/etc/openvpn/tap0-br.conf** of OpenVPN A and **/etc/openvpn/tap0-br.conf** of OpenVPN B.

```
# point to the peer
remote 192.168.8.174
dev tap0
secret /etc/openvpn/secrouter.key
cipher DES-EDE3-CBC
auth MD5
tun-mtu 1500
tun-mtu-extra 64
ping 40
#up /etc/openvpn/tap0-br.sh
#comp-lzo
```

Routed IP

- Set up four machines, as shown in the following diagram:



- On machine OpenVPN A, modify the remote address in configuration file **/etc/openvpn/tun.conf**.

```

# point to the peer
remote 192.168.8.174
dev tun
secret /etc/openvpn/secrouter.key
cipher DES-EDE3-CBC
auth MD5
tun-mtu 1500
tun-mtu-extra 64
ping 40
ifconfig 192.168.2.173 192.168.4.174
up /etc/openvpn/tun.sh
-----
  
```

- Next, modify the routing table in script file **/etc/openvpn/tun.sh**.

```

-----Start-----
#!/bin/sh
# value after "-net" is the subnet behind the remote peer
route add -net 192.168.2.0 netmask 255.255.255.0 gw $5
-----end-----
  
```

- On machine OpenVPN B, modify the remote address in configuration file **/etc/openvpn/tun.conf**.

```

# point to the peer
remote 192.168.8.173
dev tun
secret /etc/openvpn/secrouter.key
cipher DES-EDE3-CBC
auth MD5
tun-mtu 1500
tun-mtu-extra 64
ping 40
ifconfig 192.168.4.174 192.168.2.173
up /etc/openvpn/tun.sh
  
```

And then modify the routing table in script file **/etc/openvpn/tun.sh**.

```
#-----Start-----
#!/bin/sh
# value after "-net" is the subnet behind the remote peer
route add -net 192.168.2.0 netmask 255.255.255.0 gw $5
#-----end-----
```

The first argument of parameter **ifconfig** is the local internal interface and the second argument is the internal interface at the remote peer.

\$5 is the argument that the OpenVPN program passes to the script file. Its value is the second argument of **ifconfig** in the configuration file.

5. Check the routing table after you run the OpenVPN programs, by typing the **# route** command.

Destination	Gateway	Genmask	Flags	Metric	Ref	Use	Iface
192.168.4.174	*	255.255.255.255	UH	0	0	0	tun0
192.168.4.0	192.168.4.174	255.255.255.0	UG	0	0	0	tun0
192.168.2.0	*	255.255.255.0	U	0	0	0	eth1
192.168.8.0	*	255.255.255.0	U	0	0	0	eth0

4

Programming Guide

The following topics are covered in this chapter:

- ❑ **Device API**
- ❑ **RTC (Real Time Clock)**
- ❑ **UART**
- ❑ **Programmable LED, Power Indicator, and Relay control**
- ❑ **WDT (Watch Dog Timer)**
 - Introduction
 - Watchdog Usage
 - How the WDT Works
 - The Watchdog Device IOCTL Commands
 - Examples

Device API

The DA-720 supports control devices with the **ioctl** system API. The interface is shown below:

```
int ioctl(int d, int request,...);
Input:
  <d> open device node return file handle
  <request> argument in or out
```

Refer to desktop Linux's man page for detailed documentation:

```
#man ioctl
```

RTC (Real Time Clock)

The device node is located at **/dev/rtc**. The DA-720-LX supports standard Linux simple RTC control. You must include **<linux/rtc.h>**.

1. Function: RTC_RD_TIME

```
int ioctl(fd, RTC_RD_TIME, struct rtc_time *time);
Description: read time information from the RTC. It will return the value on
argument 3.
```

2. Function: RTC_SET_TIME

```
int ioctl(fd, RTC_SET_TIME, struct rtc_time *time);
Description: set RTC time. Argument 3 will be passed to RTC.
```

UART

The normal tty device nodes are **/dev/ttys0** and **/dev/ttys1**. The DA-720 supports standard Linux terminal I/Os (termios) control functions for serial ports. The **setinterface** utility can be used to configure the RS-232/422/485 mode. By default, the serial interface is set to RS-232.

setinterface device-node [interface-no]

```
device-node: /dev/ttysn; n = 0,1,2,...
interface-no: (See the table below for details.)
```

interface-no	Operation Mode
None	Display current setting
0	RS-232
1	2-wire RS-485
2	RS-422
3	4-wire RS-485

For example, use the following commands to set **/dev/ttym0** to **RS-422**:

```
Moxa:~# setinterface /dev/ttym0 2
Moxa:~# setinterface /dev/ttym0
Now setting is RS422 interface.
Moxa:~#
```

Programmable LED, Power Indicator, and Relay control

Digital Output channels can be set to high or low. The channels are controlled by /sys file. The mapping table for programmable LEDs and relay is given below:

Function	GPIO number	Sysfs file
pled1	355	/sys/class/gpio/pled1/value
pled2	356	/sys/class/gpio/pled2/value
pled3	357	/sys/class/gpio/pled3/value
pled4	358	/sys/class/gpio/pled4/value
pwrin1	353	/sys/class/gpio/pwrin1/value
pwrin2	354	/sys/class/gpio/pwrin2/value
relay1	359	/sys/class/gpio/relay1/value

The Programmable LED, Power Indicator, and Relay can be accessed via /sys/class/gpio/gpioN/value. All the GPIO sysfs files have been exported by /etc/systemd/system/multi-user.target.wants/mx_gpio_export.service at boot sequence. You don't need to export the GPIO entry. You can use the **echo** command to control the GPIO directly in a shell program.

To set pled1 to status low:

```
moxa@Moxa:~# sudo echo 0 > /sys/class/gpio/pled1/value
```

To set pled1 to status high:

```
moxa@Moxa:~# sudo echo 1 > /sys/class/gpio/pled1/value
```

To read the pled1 status:

```
moxa@Moxa:~# sudo cat /sys/class/gpio/pled1/value
```

To control the relay:

```
moxa@Moxa:~# sudo echo "0" > /sys/class/gpio/relay1/value
<...Wait relay activated ... >
moxa@Moxa:~# sudo echo "1" > /sys/class/gpio/relay1/value
```

To set the pled1 value in C:

```
sprint(buf, "/sys/class/gpio/pled%d/value", gpio);

fd = open(buf, O_WRONLY);

// Set GPIO high status
write(fd, "1", 1);
// Set GPIO low status
write(fd, "0", 1);

close(fd);
```

To get the value of pwrind1 in C:

```
Sprint(buf, "/sys/class/gpio/pwrind%d/value", gpio);

fd = open(buf, O_RDONLY);

read(fd, &value, 1);

if(value == '0')
{
    // Current GPIO status low
}
else
{
    // Current GPIO status high
}
close(fd);
```

WDT (Watch Dog Timer)

Introduction

The WDT works like a watchdog function, and can be enabled or disabled. When the WDT function is enabled and the application does not acknowledge it, the system will reboot.

Watchdog Usage

You can set the acknowledge time from a minimum of 1 sec to a maximum of 1day. The default is 60 seconds. So, if the watchdog daemon crashes, the system will reboot after the timeout period has passed.

How the WDT Works

Debian project supports a watchdog daemon. The watchdog daemon checks if your system is still working. If programs are no longer executed it will perform the hard reset of the system. The standard watchdog driver and package have been installed in the system. If you need to run the watchdog once the system boots up, you can use the **insserv** command to enable the watchdog function.

```
moxa@Moxa:~# sudo insserv -v -d wd_keepalive
insserv: enable service ..../init.d/wd_keepalive ->
/etc/init.d/../rc2.d/S01wd_keepalive
insserv: enable service ..../init.d/wd_keepalive ->
/etc/init.d/../rc3.d/S01wd_keepalive
insserv: enable service ..../init.d/wd_keepalive ->
/etc/init.d/../rc4.d/S01wd_keepalive
insserv: enable service ..../init.d/wd_keepalive ->
/etc/init.d/../rc5.d/S01wd_keepalive
insserv: creating .depend.boot
insserv: creating .depend.start
insserv: creating .depend.stop
moxa@Moxa:~$ sudo insserv -v -d watchdog
[sudo] password for moxa:
insserv: enable service ..../init.d/watchdog -> /etc/init.d/../rc0.d/K01watchdog
```

```

insserv: enable service ../init.d/watchdog -> /etc/init.d/.../rc1.d/K01watchdog
insserv: enable service ../init.d/watchdog -> /etc/init.d/.../rc2.d/S23watchdog
insserv: enable service ../init.d/watchdog -> /etc/init.d/.../rc3.d/S23watchdog
insserv: enable service ../init.d/watchdog -> /etc/init.d/.../rc4.d/S23watchdog
insserv: enable service ../init.d/watchdog -> /etc/init.d/.../rc5.d/S23watchdog
insserv: enable service ../init.d/watchdog -> /etc/init.d/.../rc6.d/K01watchdog
insserv: creating .depend.boot
insserv: creating .depend.start
insserv: creating .depend.stop
moxa@Moxa:~$
```

The watchdog configuration file is **/etc/watchdog.conf**. Currently we configure the watchdog daemon to acknowledge the watchdog device in 60 seconds. The **realtime** parameter in the configuration file is used to specify if the watchdog is locked in memory (**yes=lock**) so as to prevent a delay in watchdog acknowledge. You can configure the **watchdog.conf** file to enable the watchdog as per the system requirement.

```

...
watchdog-device = /dev/watchdog
...
interval          = 60
realtime          = yes
priority          = -10
...
```

If you want to remove it from run-level, you can use this command:

```

moxa@Moxa:~# sudo insserv -v -r watchdog
insserv: remove service /etc/init.d/.../rc0.d/K01watchdog
insserv: remove service /etc/init.d/.../rc1.d/K01watchdog
insserv: remove service /etc/init.d/.../rc2.d/S05watchdog
insserv: remove service /etc/init.d/.../rc3.d/S05watchdog
insserv: remove service /etc/init.d/.../rc4.d/S05watchdog
insserv: remove service /etc/init.d/.../rc5.d/S05watchdog
insserv: remove service /etc/init.d/.../rc6.d/K01watchdog
insserv: creating .depend.boot
insserv: creating .depend.start
insserv: creating .depend.stop
moxa@Moxa:~# sudo insserv -v -r wd_keepalive
insserv: remove service /etc/init.d/.../rc2.d/S01wd_keepalive
insserv: remove service /etc/init.d/.../rc3.d/S01wd_keepalive
insserv: remove service /etc/init.d/.../rc4.d/S01wd_keepalive
insserv: remove service /etc/init.d/.../rc5.d/S01wd_keepalive
insserv: creating .depend.boot
insserv: creating .depend.start
insserv: creating .depend.stop
```

The Watchdog Device IOCTL Commands

IOCTL	WDIOC_GETSUPPORT
Description	This returns the support of the card itself
Input	None
Output	(struct watchdog_info *) arg
Return	On success, return 0. Otherwise, return < 0 value.

IOCTL	WDIOC_GETSTATUS
Description	This returns the status of the card
Input	None
Output	(int *)arg
Return	On success, return 0. Otherwise, return < 0 value.

IOCTL	WDIOC_GETBOOTSTATUS
Description	This returns the status of the card that was reported at boot-up.
Input	None
Output	(int *)arg
Return	On success, return 0. Otherwise, return < 0 value.

IOCTL	WDIOC_SETOPTIONS
Description	This lets you set the options of the card. You can either enable or disable the card this way.
Input	None
Output	(int *)arg
Return	On success, return 0. Otherwise, return < 0 value.

IOCTL	WDIOC_KEEPALIVE
Description	This pings the card to tell it not to reset your computer.
Input	None
Output	None
Return	On success, return 0. Otherwise, return < 0 value.

IOCTL	WDIOC_SETTIMEOUT
Description	Set the watchdog timeout
Input	arg: 1 ~ 255 seconds
Output	None
Return	On success, return 0. Otherwise, return < 0 value.

IOCTL	WDIOC_GETTIMEOUT
Description	Get the current watchdog timeout.
Input	None
Output	arg: 1 ~ 255 seconds
Return	On success, return 0. Otherwise, return < 0 value.

Examples

The example file **watchdog-simple.c** acks the watchdog every 10 seconds.

```
#include <stdio.h>
#include <stdlib.h>
#include <unistd.h>
#include <fcntl.h>

int main(void)
{
    int fd = open("/dev/watchdog", O_WRONLY);
    int ret = 0;
    if (fd == -1) {
        perror("watchdog");
        exit(EXIT_FAILURE);
    }
    while (1) {
        ret = write(fd, "\0", 1);
        if (ret != 1) {
            ret = -1;
            break;
        }
        sleep(10);
    }
    close(fd);
    return ret;
}
```

5

System Recovery

The DA-720 are installed with the Embedded Linux operating system, which is located in the Flash DOM (CompactFlash card) shipped with the DA-720-LX computer. Although it rarely happens, you may find on occasion that operating system files and/or the disk file system have been damaged. In this chapter we describe how to recover the Linux operating system.

The following topics are covered in this chapter:

- Recovery Environment**
- Recovery Procedure**

Recovery Environment

The recovery environment includes the DA-720 embedded computer and a bootable USB disk with the recovery programs and system image file.

Hardware


The hardware used includes a PC, a DA-720 computer and a USB disk with the recovery programs. (**Note: The USB disk should be at least 2GB.**)



Recovery Procedure


Step 1: Prepare your USB drive

1. Execute **tuxboot-0.8.3.exe** from the **utility_tools/CloneZilla** folder on the Software CD, select **Pre Download**, and then click "...".




2. Select the ISO file in the directory of <Software DVD>


\Recovery\DA-720-LX_Recovery\CloneZilla\




3. Select **USB Drive** type, select a **Drive**, and then click **OK** to continue.



4. The boot files will be copied to your USB drive.



5. When finished, click **Exit** to stop the program.




6. Manually copy the **os_image** directory from the <Software DVD> \Recovery\DA-720-LX_Recovery\CloneZilla\ folder on the Software DVD to \home\partimag\ on the USB drive.

Step 2: Boot from USB Disk

You will need to change the BIOS settings to boot from the USB disk.

1. Turn on the computer and press **F2**. Select **Boot Manager** in the following screen:




2. Select **Target USB Disk**. Press **Enter** to continue.


Step 3: Restore the system from USB drive

Connect the USB disk to any of the DA-720's USB ports and then reboot the computer. The system will boot from the USB disk and the **Moxa System Save and Restore Utility** window is displayed.


1. Select **clonezilla live restore disk**.




2. Select a language



3. Select a policy for handling keymaps.



4. Wait for image check process complete



5. Enter **y** to continue the restore process.


6. Enter **y** to confirm again.

```


Partition table file for disk was found: sda
MBR file for this disk was found: sda
The image of this partition is restorable: sda1
All the images of partition or LV devices in this image were checked and they are restorable: os_image
=====
Activating the partition info in /proc... done!
Getting /dev/sda1 info...
*****
The following step is to restore an image to the hard disk/partition(s) on this machine: "/home/partimage/os_image" -> "sda sda1"
The image was created at: 2016-0914-1012
WARNING!!! WARNING!!! WARNING!!!
WARNING. THE EXISTING DATA IN THIS HARDDISK/PARTITION(S) WILL BE OVERWRITTEN! ALL EXISTING DATA WILL BE LOST!
*****
Machine: VMware Virtual Platform
sda (21.5GB_Vmware_Virtual_S_No_disk_serial_no)
sda1 (20G_boot(In_Vmware_Virtual_S)_No_disk_serial_no)
*****
Are you sure you want to continue? (y/n) y
OK, let's do it!!
This program is not started by clonezilla server.
*****
Let me ask you again.
The following step is to restore an image to the hard disk/partition(s) on this machine: "/home/partimage/os_image" -> "sda sda1"
The image was created at: 2016-0914-1012
WARNING!!! WARNING!!! WARNING!!!
WARNING. THE EXISTING DATA IN THIS HARDDISK/PARTITION(S) WILL BE OVERWRITTEN! ALL EXISTING DATA WILL BE LOST!
*****
Machine: VMware Virtual Platform
sda (21.5GB_Vmware_Virtual_S_No_disk_serial_no)
sda1 (20G_boot(In_Vmware_Virtual_S)_No_disk_serial_no)
*****
Are you sure you want to continue? (y/n) -

```

7. Wait for the process to finish.



8. Select **Poweroff** to power off the computer.



9. Remove the USB drive after the computer has been powered off.

6

DA-720 Expansion Module

The following topics are covered in this chapter:

□ DE-PRP-HSR-EF

- Installing the HSR/PRP Module Utility
- The HSR/PRP Module Utility

□ DE-2-IRIGB-4-DI/DO

- Installing the IRIG-B Driver in Linux
- Using the timesync Daemon in Linux
- Using the IRIG-B Utility in Linux

DE-PRP-HSR-EF

Installing the HSR/PRP Module Utility

Linux Platform

1. Install the HSR/PRP module on Moxa's embedded computer.

There are two ways to install the HSR/PRP utility and status daemon on Moxa's embedded computers. One way is to install it from Moxa's APT server. Another is off-line installation. You can choose one of these methods to install the HSR/PRP packages on Moxa's embedded computers.

2. Add acpi_enforce_resources=lax in the **grub** option

```
root@Moxa:~# sudo vi /etc/default/grub
...
# add acpi_enforce_resources=lax to GRUB_CMDLINE_LINUX_DEFAULT line
GRUB_CMDLINE_LINUX_DEFAULT="quiet 8250.nr_uarts=2 video=DP-1:1024x768
acpi_enforce_resources=lax"
root@Moxa:~# sudo update-grub
root@Moxa:~# sudo reboot
```

3. Install the packages required for the HSR/PRP module utility.

Online Installation

- a. Update /etc/apt/sources.list with Moxa's apt server

```
root@Moxa:~# sudo vi /etc/apt/sources.list
...
# Moxa debian package server
deb http://debian.moxa.com/debian jessie main
```

- b. Install the HSR/PRP package from Moxa' apt server

- c. Update the package list

```
root@Moxa:~# sudo apt-get update
```

- d. Check the mxhsrppr package

```
root@Moxa:~# sudo apt-cache search mxhsrppr
mxhsrppr-da720 - Moxa HSR/PRP Card Utility for DA-720, DA-682B
```

- e. Install the HSR/PRP utility and status daemon

```
root@Moxa:~# sudo apt-get install mxhsrppr-da720
```

- f. After that, the HSR/PRP utility and status daemon should be installed. The status daemon should be running with default configure.

```
root@Moxa:~# ps -aux | grep mxhsrprpd
root      2000  1.2  0.0  88332   96 ?        S1  Oct30  17:46
/usr/local/bin/mxhsrprpd -b /dev/i2c-0 -t 2 -B
```

Offline Installation

- Upload or copy the private key and packages to target da720-mxhsrprp_1.0.0_amd64.deb
- Install the HSR/PRP utility and status daemon

```
root@Moxa:/home/moxa/DebianServer# dpkg -i da720-mxhsrprp_1.0.0_amd64.deb
```

- After that, the HSR/PRP utility and status daemon should be installed. The status daemon should be running with default configure.

```
root@Moxa:~# ps -aux | grep mxhsrprpd
root      2000  1.2  0.0  88332   96 ?        S1   Oct30  17:46
/usr/local/bin/mxhsrprpd -b /dev/i2c-0 -t 2 -B
```

The HSR/PRP Module Utility

Linux Platform

The HSR/PRP module utility is locate at /usr/local/bin.

Program	Usage
mxhsrprpd	Used to set the HSR or PRP mode and correct the HSR/PRP protocol statistics.
mxprpinfo	Depending on the setting in the mxhsrprpd, this program is used to either get HSR/PRP protocol statistics or set the HSR/PRP mode.
chk-mx-prp-card	Reports on the current HSR/PRP module name on the Ethernet
mxprpsuper	Sends the HSR/PRP supervision frame Moxa HSR/PRP module.
mxprpalarm	This program is called by mxhsrprpd when the Link status has changed. The action should be modified by user.

mxhsrprpd

This HSR/PRP module status daemon is used to set the HSR or PRP mode and correct the HSR/PRP protocol statistics.

```
root@Moxa:~# mxhsrprpd -h
Usage:
  -h: Show this information.
  -B: Run daemon in the background
  -b: SMBUS device, default is /dev/i2c-0
  -t: HSR/PRP Status update period. Default is 2 second.
  -m: configure to prp or hsr mode, default is prp mode.
    The argument is [index]:[mode]
    index range from 0~7, mode 0 is prp, mode 1 is hsr.
    Ex: Set card 0 to hsr mode, card 1 to prp mode.
```

Usage example: Set status update interval to 2 seconds and set Card 0 to HSR mode and Card 1 to PRP mode.

```
root@Moxa:~# mxhsrprpd -t 2 -m 0:1,1:0
```

Configuring the HSR/PRP Status Daemon

The HSR/PRP status daemon is managed by the /etc/init.d/mx_prp.sh script. The default configuration, MX_PRP_OPTS is available at /etc/init.d/mx_prp.sh.

```
root@Moxa:~# sudo vi /etc/init.d/mx_prp.sh
...
MX_PRP_OPTS="-t 2 -B"
...
```

After you configure it, restart the daemon as follows:

```
root@Moxa:~# sudo /etc/init.d/mx_prp.sh restart
```

mxprpinfo

This program is used to get the HSR/PRP protocol statistics or set the HSR/PRP mode.

```
root@Moxa:~# mxprpinfo -h
Usage:
      -h: Show this information.
      -l: Show link status.
      -s: Show link speed.
      -c: Show counter.
      -m: Show current mode. 0 is PRP, 1 is HSR.
      -p: Set current mode. 0 is PRP, 1 is HSR.
      -i: Specify card index, the range is 0~7
```

Usage example: Get the mode, counters, and link status of the HSR/PRP module.

```
root@Moxa:/home/moxa# mxprpinfo -l -c -m
Mode:
index:1
mode:0

Link Status:
index:1
link_status_i:1
link_status_a:1
link_status_b:1

Counters:
index:1

port: interlink
rx_good_octets:192
...
port: lana
rx_good_octets:2516630
...
port: lanb
rx_good_octets:2516630
...
```

Usage example: Set the PRP mode on card index 1

```
root@Moxa:/home/moxa# mxprpinfo -i 1 -p 0
Set HSR/PRP mode:
index:1, curr: 0, new:0
```

chk-mx-prp-card

This program is used to get the Ethernet interface name of the Moxa HSR/PRP module.

```
root@Moxa:/home/moxa# chk-mx-prp-card
Searching Moxa HSR/PRP card...
eth14 - pcibus id is 0000:13:00.0
```

mxprpsuper

This program is used to send the HSR/PRP supervision frame. You can get the interface name using the chk-mx-prp-card program.

```
root@Moxa:/home/moxa# mxprpsuper
This progarm use to send supervision frame to Moxa HSR/PRP Card.

Usage:
-h: Show this information.
-t: send HSR/PRP supervision frame period.
      Default is 2 second.
-m: send HSR or PRP supervision frame mode.
      0 is PRP; 1 is HSR. Default is 0.
-i: interface name, Ex.: eth0.
      Execute chk-mx-prp-card to list supported interface.
-a: Destination MAC address last byte.
      The range is 00~FF. Default is 00
```

Usage example: Send the PRP supervision frame to eth14 in the time period of 2 seconds. The program should run in the background.

```
root@Moxa:/home/moxa# mxprpsuper -t 2 -m 0 -i eth14 &
```

mxprpalarm

This script is called by the mxhsrprpd program when the HSR/PRP link status changes.
The script can be modified as necessary.

```
root@Moxa:/home/moxa# vi /usr/local/bin/mxprpalarm
#!/bin/bash
#
# This shell script will call by mxhsrprpd.
# You can design custom action in this script. Please search 'TODO'
#
# $1 - Card index, 0~7.
# $2 - Event name
#       li: inter link status
#       la: lan A link statthus
```

```
#           lb: lab B link status
# $3 - Event argument
#
#
function run_alarm_link_down()
{
    echo "Card $1 $2 Link down"
...
}

function run_alarm_link_up()
{
echo "Card $1 $2 Link up"
...
}

#
# Process inter link status event
#
if [ x"$2" = x"li" ]; then
    #TODO: do something when event occur
    if [ x"$3" = x"0" ]; then
        run_alarm_link_down $1 "Interlink"
    elif [ x"$3" = x"1" ]; then
        run_alarm_link_up $1 "Interlink"
    fi
elif [ x"$2" = x"la" ]; then
#
# Process Lan A link status event
#
    #TODO: do something when event occur
    if [ x"$3" = x"0" ]; then
        run_alarm_link_down $1 "LAN A"
    elif [ x"$3" = x"1" ]; then
        run_alarm_link_up $1 "LAN A"
    fi
elif [ x"$2" = x"lb" ]; then
#
# Process Lan B link status event
#
    #TODO: do something when event occur
    if [ x"$3" = x"0" ]; then
        run_alarm_link_down $1 "LAN B"
    elif [ x"$3" = x"1" ]; then
        run_alarm_link_up $1 "LAN B"
    fi
fi
```

DE-2-IRIGB-4-DI/DO

Installing the IRIG-B Driver in Linux

NOTE The driver for the DE-2-IRIGB-4-DI/DO module supports only Debian 8 Linux distribution (kernel version 4.6.x). Before you install the driver in a different Linux distribution or kernel version, contact your Moxa sales representative for assistance.

You can install the Linux driver for the DE-2-IRIGB-4-DI/DO module on the embedded computer using one of the following methods:

- Online from Moxa's APT server
- Off-line

Online Installation

1. Make sure that your embedded computer has access to the Internet.
2. If the unzip package is not installed on the computer, run the following command to install it.

```
root@Moxa:~# sudo apt-get install unzip
```

3. Download Moxa's Debian server public key (NEW-MOXA-SYS-DEBIAN-KEY) to the /home/ directory on your target computer.

```
root@Moxa:~# sudo wget  
http://www.moxa.com/drivers/UC/MOXA_SYS_DEB_KEY/MOXA-SYS-DEBIAN-KEY.zip
```

4. Unzip and Install Moxa's public key file on the embedded computer (for example, DA-682A).

```
root@Moxa:~# sudo unzip MOXA-SYS-DEBIAN-KEY  
root@Moxa:~# cd MOXA-SYS-DEBIAN-KEY  
root@Moxa:~# sudo apt-key add NEW-MOXA-SYS-DEBIAN-KEY
```

5. In the /etc/apt/sources.list file, insert one of the following lines to add the Moxa APT server:

```
deb http://debian.moxa.com/debian jessie main
```

The following figure shows an example.

```
root@Moxa:~# sudo vi /etc/apt/sources.list  
...  
# Add Moxa's apt server  
deb http://debian.moxa.com/debian jessie
```

6. Install the irigb package from Moxa's APT server. Complete the following steps:

- a. Update the package list.

```
root@Moxa:~# sudo apt-get update
```

- b. Check the irigb package.

```
root@Moxa:~# sudo apt-cache search irigb  
da-720-irigb-driver - Moxa DA-720 IRIG-B module device driver  
da-720-irigb-timesync-daemon - Moxa DA-720 IRIG-B time sync daemon
```

- c. Install the IRIG-B driver and the timesync daemon. Follow the on-screen instruction. The following figure shows the installation screen for the DA-720.

```
root@Moxa:~# sudo apt-get install da-720-irigb-timesync-daemon  
Reading package lists... Done  
Building dependency tree
```

```

Reading state information... Done
The following extra packages will be installed:
  da-720-irigb-driver

The following NEW packages will be installed:
  da-720-irigb-driver da-720-irigb-timesync-daemon

0 upgraded, 2 newly installed, 0 to remove and 83 not upgraded.
Need to get 77.8 kB of archives.

After this operation, 0 B of additional disk space will be used.

Do you want to continue [Y/n]? Y
Get:1 http://debian.moxa.com/debian jessie/main da-720-irigb-driver amd64 1.0
[67.7 kB]
Get:2 http://www.moxa.com/debian jessie/main da-720-irigb-timesync-daemon
amd64 1.3 [10.1 kB]
Fetched 77.8 kB in 0s (851 kB/s)
Selecting previously unselected package da-720-irigb-driver.
(Reading database ... 31660 files and directories currently installed.)
Unpacking da-720-irigb-driver
(from .../da-720-irigb-driver_1.0_amd64.deb) ...
Selecting previously unselected package da-720-irigb-timesync-daemon.
Unpacking da-720-irigb-timesync-daemon
(from .../da-720-irigb-timesync-daemon_1.3_amd64.deb) ...
Setting up da-720-irigb-driver (1.0) ...
WARNING: -e needs -E or -F
Setting up da-720-irigb-timesync-daemon (1.3) ...

```

6. Verify that the driver is loaded and the time sync daemon is running.

- Use the `lsmod` command to check whether the IRIG-B module is loaded.

```

root@Moxa:~# lsmod|grep irig
moxa_irigb           12683  1

```

- Verify that the timesync daemon is running with the default configuration.

```

root@Moxa:~# ps aux|grep ServiceSyncTime
root      3078  0.0  0.1 16136  1140 ?        S    10:43   0:00
/usr/sbin/ServiceSyncTime -t 1 -i 10 -B

```

Off-Line Installation

- Download the driver from the Moxa web site at <http://www.moxa.com>.
- Upload or copy the following files to the embedded computer (for example, DA-720):
 - NEW-MOXA-SYS-DEBIAN-KEY
 - DA-720-irigb-driver-1.0_amd64.deb
 - DA-720-irigb_timesync_daemon_1.3_amd64.deb
- Install Moxa's public key file on the embedded computer (for example, DA-720).

```

root@Moxa:~# sudo apt-key add NEW-MOXA-SYS-DEBIAN-KEY

```

- Install the IRIG-B driver and the timesync daemon. Follow the on-screen instruction.

```

root@Moxa:/home/moxa# dpkg -i DA-720-irigb-driver_1.0_amd64.deb
Selecting previously unselected package da-720-irigb-driver.
(Reading database ... 51077 files and directories currently installed.)
Preparing to unpack DA-720-irigb-driver_1.0_amd64.deb ...

```

```

Unpacking da-720-irigb-driver (1.0) ...
Setting up da-720-irigb-driver (1.0) ...

root@Moxa:/home/moxa# dpkg -i DA-720-irigb_timesync_daemon_1.3_amd64.deb
Selecting previously unselected package da-720-irigb-timesync-daemon.
(Reading database ... 51077 files and directories currently installed.)
Unpacking da-720-irigb-timesync-daemon (from
DA-720-irigb_timesync_daemon_1.3_amd64.deb) ...
Setting up da-720-irigb-timesync-daemon (1.3) ...

```

5. Verify that the driver is loaded and the time sync daemon is running.

- a. Use the `lsmod` command to check whether the IRIG-B module is loaded.

```

root@Moxa:~# lsmod|grep irig
moxa_irigb          12683  1

```

- b. Verify that the timesync daemon is running with the default configuration.

```

root@Moxa:~# ps aux|grep ServiceSyncTime
root      3078  0.0  0.1 16136 1140 ?        S    10:43   0:00
/usr/sbin/ServiceSyncTime -t 1 -i 10 -B

```

Using the timesync Daemon in Linux

The following figure shows the help information of the timesync daemon.

```

root@Moxa:~# ServiceSyncTime -h
Found the IRIG-B module, Hardware ID = 1
IRIG-B time sync daemon.

Usage: ServiceSyncTime -t [signal type] -I -d -i [Time sync interval] -p [Parity check
mode] -B
-t - [signal type]
  0 - TTL
  1 - DIFF
  default value is 1
-I - inverse the input or output signal
-d - Disable time sync
  Default this daemon enables the IRIG-B time sync from source port to system time.

-i - [Time sync interval] The time interval in seconds to sync the IRIG-B time
into system time.
  1 ~ 86400 Time sync interval. Default is 10 second.
-p - [Parity check mode] Set the parity bit
  0: EVEN
  1: ODD
  2: NONE
  default value is 0
-B - Run daemon in the background

Usage example: Enable to sync time from IRIG-B Port 1, in TTL signal type every 10
seconds. The input is not inverse.
root@Moxa:~# ServiceSyncTime -t 0 -i 10

```

Examples

The following command example enables the daemon to synchronize time from Port 1 in DIFF signal type every 10 seconds. The input signal is not inverted. The ServiceSyncTime process runs in the foreground.

```
root@Moxa:~# ServiceSyncTime -t 1 -i 10
```

The following command example enables the daemon to synchronize time from Port 1 in DIFF signal type every 10 seconds with ODD parity check mode. The ServiceSyncTime process runs in the foreground.

```
root@Moxa:~# ServiceSyncTime -t 1 -i 10 -p 1
```

The following command example enables the daemon to synchronize time from Port 1 in DIFF signal type every 10 seconds and inverse the signal if the cable cross-connect. The ServiceSyncTime process runs in the foreground.

```
root@Moxa:~# ServiceSyncTime -t 1 -i 10 -I
```

Configuring the timesync Daemon

You can edit the **/etc/init.d/mx_irigb.sh** file to configure the timesync daemon. The script also includes the default settings for MX_IRIGB_OPTS.

```
root@Moxa:~# sudo vi /etc/init.d/mx_irigb.sh
...
MX_IRIGB_SERVICESYNCTIME_OPTS="-t 1 -i 10 -B"
...
```

After you change the settings in the **/etc/init.d/mx_irigb.sh** file, restart the daemon.

```
root@Moxa:~# sudo service mx_irigb.sh restart
```

Using the IRIG-B Utility in Linux

The mxIrigUtil command is available in the destination folder that you selected during the installation process. The list of available parameters and options for the mxIrigUtil command is the same in Linux and Windows 7.

The following figure shows the help information for the IRIG-B utility.

```
root@Moxa:~# mxIrigUtil -h
Get/set Moxa DA-IRIGB utility
Usage: mxIrigUtil -f function_id [-p parameters] [-c] [-h]
      Show the utility information if no argument apply.
      -h: Show this information.
      -c: Indicate the n-the IRIG-B Card.
      -f: Pass function id argument to execute specify functionality
      -p: Parameters for each function, use comma to pass multiple variable
```

For example: Set IRIG-B RTC Time 2014/01/01 03:25:00

```
mxIrigUtil -f 2 -p 2014,1,1,3,25,0
```

Function description list:

```
0:Get Hardware ID
1:Get IRIG-B RTC Time
```

```

2:Set IRIG-B RTC Time
  -p [2000-2099],[1-12],[1-31],[0-23],[0-59],[0-59]
  (year[2000-2099],month[1-12],day[1-31],hour[0-23],min[0-59],sec[0-59]); default
  value is 2014,01,01,00,00,00

3:Get IRIG-B RTC Sync. Source

4:Set IRIG-B RTC Sync. Source
  -p [0-2] (Source: 0=FreeRun In (Internal RTC), 1=Fiber In, 2=Port 1 In);
  default value is 2

5:Get IRIG-B Signal Status
  -p [1-2] (Source: 1=Fiber In, 2=Port 1 In); default value is 2

6:Get IRIG-B Input Parity Check Mode
  -p Source[1-2] (1=Fiber In, 2=Port 1 In); default value is 2

7:Set IRIG-B Input Parity Check Mode
  -p Source[1-2] (1=Fiber In, 2=Port 1 In),Mode[0-2] (0=Even, 1=Odd, 2=None);
  default value is 2,0

8:Get IRIG-B Output Parity Check Mode

9:Set IRIG-B Output Parity Check Mode
  -p Mode[0-1] (0=Even, 1=Odd); default value is 0

10:Get Pulse per second width(ms)

11:Set Pulse per second width(ms)
  -p [0-999] (width: 0-999 ms); default value is 0

12:Get input signal type
  -p [0-1] 0=Fiber, 1=Port 1 (port[0-1]); default value is 1

13:Set input signal type
  -p [0-1],[0-1],[0-1]
    (port[0-1]: 0=Fiber 1=Port 1,
     signal type[0-1]: 0=TTL, 1=DIFF,
     inverse[0-1]: 0=No inverse 1=Inverse)
    default value is 1,1,0

14:Get output signal type
  -p [1-4] (output port[1-4]); default value is 1

15:Set output signal type
  -p [1-4],[0-1],[0-3],[0-1]
    (output port[1-4]: Output port 1-4,
     signal type[0-1]: 0=TTL, 1=DIFF,
     mode[0-3]: 0=From Fiber Input Port, 1=From Port 1 Input, 2=From
                 IRIG-B encode(Internal RTC), 3=From PPS encode;
     inverse[0-1]: 0=No inverse, 1=Inverse)
    default value is 1,1,2,0

16:Get Digital Output
  -p [0-3] (digital output port[0-3]); default value is 0

17:Set Digital Output
  -p [0-3],[0-1] (digital output port[0-3],level[0-1]); default value is 0,0

18:Get Digital Input
  -p [0-2] (digital input port[0-2]); default value is 0

```

The following table describes the function IDs.

Function ID	Function description	Parameters
0	Display the hardware device ID. For example, Hardware ID = 1 (DE2_IRIGB_4DIO)	N/A
1	Display current internal RTC time.	N/A
2	Set internal RTC time	yyyy,MM,dd,hh,mm,ss Where yyyy is the year (2000 – 2099). MM is the month (1-12). dd is the day of the month (1-31). hh is the hour of the day (0 -23). mm is the minute (0-59). ss is the second (0-59).
3	Display the RTC synchronization source.	N/A
4	Set the RTC synchronization source.	Source [0 2] Where 0 is free run. 2 is port 1 input.
5	Display IRIG-B signal status. Possible status are: 0-Normal 1-Off Line 2-Frame Error 3-Parity Error	Source [2] Where 2 is port 1 input.
6	Display IRIG-B input parity check mode. Possible modes are: 0-Even 1-Odd 2-None	Source [2] Where 2 is port 1 input.
7	Set IRIG-B input parity check mode	Source, Mode Where Source: 2 (port 1 input) Mode: 0 (Even), 1 (Odd), 2 (None)
8	Get IRIG-B Output Parity Check Mode	N/A
9	Set IRIG-B Output Parity Check Mode	Mode Where Mode: 0(Even) 1(Odd)
10	Display pulse per second width (ms).	N/A
11	Set pulse per second width (ms).	Width (0~999)
12	Display input signal type.	port [0 1] Where 1 is port 1 input.
13	Set input signal type.	port, signal type, mode, inverse Where port – 1 is “Port 1” signal type – 0 is TTL; 1 is “DIFF” inverse – 0 means do not inverse; 1 means inverse.
16	Display digital output.	port where 0 is “DO0”, 1 is “DO1”, 2 is “DO2”, and 3 is “DO3”

Function ID	Function description	Parameters
17	Set digital output.	port, level Where port – 0 is “DO0”, 1 is “DO1”, 2 is “DO2”, and 3 is “DO3” level – 0 is low and 1 is high
18	Display digital input.	port Where 0 is “DI0”, 1 is “DI1”, and 2 is “DI2”

NOTE Function IDs 8, 9, 14, and 15 are not available for the DA-IRGB-4DIO-PCI-104-EMC4 module, which does not support the fiber input port.

Examples

The following command example displays the IRIG-B module hardware ID.

```
root@Moxa:~# mxIrigUtil -f 0
Get Hardware ID = 2 (DE2_IRIGB_4DIO)
```

The following command example displays the IRIG-B module internal RTC time.

```
root@Moxa:~# mxIrigUtil -f 1
Get IRIGB RTC = 2011/11/11 17:29:55.204137520, TZ = +8, TQ = 6
```

The following command example sets the IRIG-B module internal RTC time to 2014/11/19 11:19:50.

```
root@Moxa:~# mxIrigUtil -f 2 -p 2014,11,19,11,19,50
Set IRIGB RTC = 2014/11/19 11:19:50
```

The following command example displays the IRIG-B module time sync source setting. In this example, the time source is IRIG-B Port 1.

```
root@Moxa:~# mxIrigUtil -f 3
Get Sync. Source = 2 (Port 1 In)
```

The following command example sets the IRIG-B module time sync source.

```
root@Moxa:~# mxIrigUtil -f 4 -p 1
Set Sync. Source = 1
```

The following command displays the IRIG-B signal status.

```
root@Moxa:~# mxIrigUtil -f 5 -p 1
Fiber In Signal Status = 1(Off Line)
root@Moxa:~# mxIrigUtil -f 5 -p 2
Port 1 In Signal Status = 2(Frame Error)
root@Moxa:~
```

The following command displays the pulse per second width (ms).

```
root@Moxa:~# mxIrigUtil -f 10
Get PPS Width = 0 ms
```

The following command example sets the pulse per second width (ms).

```
root@Moxa:~# mxIrigUtil -f 11 -p 5
Set PPS Width = 5 ms
```

The following command example displays the input interface.

```
root@Moxa:~# mxIrigUtil -f 12 -p 1
Get Input Port 1 Interface = 1(DIFFERENTIAL), Inverse = 0
```

The following command example displays the digital output interface.

```
root@Moxa:~# mxIrigUtil -f 16 -p 0
Get DO 0 = 1
root@Moxa:~# mxIrigUtil -f 16 -p 1
Get DO 1 = 1
root@Moxa:~# mxIrigUtil -f 16 -p 2
Get DO 2 = 1
root@Moxa:~# mxIrigUtil -f 16 -p 3
Get DO 3 = 1
root@Moxa:~# mxIrigUtil -f 16 -p 4
Get DO 4 = 1
```

The following command example sets the digital output interface.

```
root@Moxa:~# mxIrigUtil -f 17 -p 0,0
Set DO 0 = 0
root@Moxa:~# mxIrigUtil -f 17 -p 0,1
Set DO 0 = 1
root@Moxa:~# mxIrigUtil -f 17 -p 1,0
Set DO 1 = 0
root@Moxa:~# mxIrigUtil -f 17 -p 1,1
Set DO 1 = 1
root@Moxa:~# mxIrigUtil -f 17 -p 2,0
Set DO 2 = 0
root@Moxa:~# mxIrigUtil -f 17 -p 2,1
Set DO 2 = 1
root@Moxa:~# mxIrigUtil -f 17 -p 3,0
Set DO 3 = 0
root@Moxa:~# mxIrigUtil -f 17 -p 3,1
Set DO 3 = 1
```

The following command example displays the digital input interface.

```
root@Moxa:~# mxIrigUtil -f 18 -p 0
Get DI 0 = 0
root@Moxa:~# mxIrigUtil -f 18 -p 1
Get DI 1 = 0
root@Moxa:~# mxIrigUtil -f 18 -p 2
Get DI 2 = 0
```

You can edit the **/etc/init.d/mx_irigb.sh** script to configure the IRIG-B utility. For example, if you want to set the IRIG-B digital output interface, remove the '#' symbol from the `/usr/sbin/mxIrigUtil` line and configure the `MX_IRIGB_UTIL_OPTS` parameter. The following figure shows an example.

```
root@Moxa:~# sudo vi /etc/init.d/mx_irigb.sh
...
MX_IRIGB_UTIL_OPTS="-f 15 -p 1,1,2,0"
...
case "$1" in
    start)
...
        # If you need the IRIG-B signal output, you should remove the # in front of
the following line.
        /usr/sbin/mxIrigUtil $MX_IRIGB_UTIL_OPTS > /dev/null 2>&1
...
...
```

A

Software Components

Name	Version	Description
acl	2.2.52-2	Access control list utilities
acpi	1.7-1	displays information on ACPI devices
acpi-support-base	0.142-6	scripts for handling base ACPI events such as the power button
acpid	1:2.0.23-2	Advanced Configuration and Power Interface event daemon
adduser	3.113+nmu3	add and remove users and groups
anacron	2.3-23	cron-like program that doesn't go by time
apache2	2.4.10-10+deb8u5	Apache HTTP Server
apache2-bin	2.4.10-10+deb8u5	Apache HTTP Server (modules and other binary files)
apache2-data	2.4.10-10+deb8u5	Apache HTTP Server (common files)
apache2-utils	2.4.10-10+deb8u5	Apache HTTP Server (utility programs for web servers)
apt	1.0.9.8.3	Command-line package manager
apt-listchanges	2.85.13+nmu1	package change history notification tool
apt-utils	1.0.9.8.3	package management related utility programs
aptitude	0.6.11-1+b1	terminal-based package manager
aptitude-common	0.6.11-1	architecture independent files for the aptitude package manager
aptitude-doc-en	0.6.11-1	English manual for aptitude, a terminal-based package manager
at	3.1.16-1	Delayed job execution and batch processing
avahi-autoipd	0.6.31-5	Avahi IPv4LL network address configuration daemon
base-files	8+deb8u5	Debian base system miscellaneous files
base-passwd	3.5.37	Debian base system master password and group files
bash	4.3-11+b1	GNU Bourne Again SHell
bash-completion	1:2.1-4	programmable completion for the bash shell
bc	1.06.95-9	GNU bc arbitrary precision calculator language
bind9-host	1:9.9.5.dfsg-9+deb8u6	Version of 'host' bundled with BIND 9.X
binutils	2.25-5	GNU assembler, linker and binary utilities
bluetooth	5.23-2	Bluetooth support
bluez	5.23-2+b1	Bluetooth tools and daemons
bridge-utils	1.5-9	Utilities for configuring the Linux Ethernet bridge
bsd-mailx	8.1.2-0.20141216cvs-2	simple mail user agent
bsdmainutils	9.0.6	collection of more utilities from FreeBSD
bsdutils	1:2.25.2-6	basic utilities from 4.4BSD-Lite
build-essential	11.7	Informational list of build-essential packages
busybox	1:1.22.0-9+deb8u1	Tiny utilities for small and embedded systems
bzip2	1.0.6-7+b3	high-quality block-sorting file compressor - utilities

Name	Version	Description
ca-certificates	20141019+deb8u1	Common CA certificates
console-setup	1.123	console font and keymap setup program
console-setup-linux	1.123	Linux specific part of console-setup
coreutils	8.23-4	GNU core utilities
cpio	2.11+dfsg-4.1+deb8u1	GNU cpio -- a program to manage archives of files
cpp	4:4.9.2-2	GNU C preprocessor (cpp)
cpp-4.9	4.9.2-10	GNU C preprocessor
crda	3.13-1	wireless Central Regulatory Domain Agent
cron	3.0pl1-127+deb8u1	process scheduling daemon
da720-misc	1.0.0	Moxa da720 Led/Relay/On Board Serial Interface device driver
da720-mxser	1.0.0	mxser driver for DA-720 series
da720-setinterface	1.0.0	utility for mxser
da720-watchdog	1.0.0	Moxa da720 watchdog device driver
dash	0.5.7-4+b1	POSIX-compliant shell
dbus	1.8.20-0+deb8u1	simple inter process messaging system (daemon and utilities)
dc	1.06.95-9	GNU dc arbitrary precision reverse-polish calculator
debconf	1.5.56	Debian configuration management system
debconf-i18n	1.5.56	full internationalization support for debconf
debian-archive-keyring	2014.3	GnuPG archive keys of the Debian archive
debian-faq	5.0.3	Debian Frequently Asked Questions
debianutils	4.4+b1	Miscellaneous utilities specific to Debian
dictionaries-common	1.23.17	spelling dictionaries - common utilities
diffutils	1:3.3-1+b1	File comparison utilities
discover	2.1.2-7	hardware identification system
discover-data	2.2013.01.11	Data lists for Discover hardware detection system
dmidecode	2.12-3	SMBIOS/DMI table decoder
dmsetup	2:1.02.90-2.2+deb8u1	Linux Kernel Device Mapper userspace library
dnsutils	1:9.9.5.dfsg-9+deb8u6	Clients provided with BIND
doc-debian	6.2	Debian Project documentation and other documents
docutils-common	0.12+dfsg-1	text processing system for reStructuredText - common data
docutils-doc	0.12+dfsg-1	text processing system for reStructuredText - documentation
dpkg	1.17.27	Debian package management system
dpkg-dev	1.17.27	Debian package development tools
e2fslibs:amd64	1.42.12-1.1	ext2/ext3/ext4 file system libraries
e2fsprogs	1.42.12-1.1	ext2/ext3/ext4 file system utilities
easy-rsa	2.2.2-1	Simple shell based CA utility
emacsen-common	2.0.8	Common facilities for all emacsen
ethtool	1:3.16-1	display or change Ethernet device settings
fakeroot	1.20.2-1	tool for simulating superuser privileges
file	1:5.22+15-2+deb8u1	Determines file type using "magic" numbers
findutils	4.4.2-9+b1	utilities for finding files--find, xargs
firmware-linux-free	3.3	Binary firmware for various drivers in the Linux kernel
firmware-misc-nonfree	20160110-1~bpo8+1	Binary firmware for various drivers in the Linux kernel
fontconfig	2.11.0-6.3	generic font configuration library - support binaries

Name	Version	Description
fontconfig-config	2.11.0-6.3	generic font configuration library - configuration
fonts-dejavu-core	2.34-1	Vera font family derivate with additional characters
g++	4:4.9.2-2	GNU C++ compiler
g++-4.9	4.9.2-10	GNU C++ compiler
gcc	4:4.9.2-2	GNU C compiler
gcc-4.8-base:amd64	4.8.4-1	GCC, the GNU Compiler Collection (base package)
gcc-4.9	4.9.2-10	GNU C compiler
gcc-4.9-base:amd64	4.9.2-10	GCC, the GNU Compiler Collection (base package)
geoip-database	20150317-1	IP lookup command line tools that use the GeoIP library (country database)
gettext-base	0.19.3-2	GNU Internationalization utilities for the base system
gnupg	1.4.18-7+deb8u1	GNU privacy guard - a free PGP replacement
gnupg-agent	2.0.26-6	GNU privacy guard - password agent
gnupg2	2.0.26-6	GNU privacy guard - a free PGP replacement (new v2.x)
gpgv	1.4.18-7+deb8u1	GNU privacy guard - signature verification tool
grep	2.20-4.1	GNU grep, egrep and fgrep
groff-base	1.22.2-8	GNU troff text-formatting system (base system components)
grub-common	2.02~beta2-22+deb8u1	GRand Unified Bootloader (common files)
grub-pc	2.02~beta2-22+deb8u1	GRand Unified Bootloader, version 2 (PC/BIOS version)
grub-pc-bin	2.02~beta2-22+deb8u1	GRand Unified Bootloader, version 2 (PC/BIOS binaries)
grub2-common	2.02~beta2-22+deb8u1	GRand Unified Bootloader (common files for version 2)
gzip	1.6-4	GNU compression utilities
hdparm	9.43-2	tune hard disk parameters for high performance
hicolor-icon-theme	0.13-1	default fallback theme for FreeDesktop.org icon themes
host	1:9.9.5.dfsg-9+deb8u6	Transitional package
hostname	3.15	utility to set/show the host name or domain name
iamerican	3.3.02-6	American English dictionary for ispell (standard version)
ibritish	3.3.02-6	British English dictionary for ispell (standard version)
ienglish-common	3.3.02-6	Common files for British and American ispell dictionaries
ifenslave	2.6	configure network interfaces for parallel routing (bonding)
ifstat	1.1-8+b1	InterFace STATistics Monitoring
ifupdown	0.7.53.1	high level tools to configure network interfaces
info	5.2.0.dfsg.1-6	Standalone GNU Info documentation browser
init	1.22	System-V-like init utilities - metapackage
init-system-helpers	1.22	helper tools for all init systems
initramfs-tools	0.120+deb8u2	generic modular initramfs generator
initscripts	2.88dsf-59	scripts for initializing and shutting down the system
insserv	1.14.0-5	boot sequence organizer using LSB init.d script dependency information
install-info	5.2.0.dfsg.1-6	Manage installed documentation in info format

Name	Version	Description
installation-report	2.58	system installation report
iproute	1:3.16.0-2	transitional dummy package for iproute2
iproute2	3.16.0-2	networking and traffic control tools
ipsec-tools	1:0.8.2+20140711-2+d e	IPsec utilities
iptables	1.4.21-2+b1	administration tools for packet filtering and NAT
iputils-ping	3:20121221-5+b2	Tools to test the reachability of network hosts
irqbalance	1.1.0-2~bpo8+1	Daemon to balance interrupts for SMP systems
isc-dhcp-client	4.3.1-6+deb8u2	DHCP client for automatically obtaining an IP address
isc-dhcp-common	4.3.1-6+deb8u2	common files used by all of the isc-dhcp packages
isc-dhcp-server	4.3.1-6+deb8u2	ISC DHCP server for automatic IP address assignment
iso-codes	3.57-1	ISO language, territory, currency, script codes and their translations
ispell	3.3.02-6	International Ispell (an interactive spelling corrector)
iw	3.17-1	tool for configuring Linux wireless devices
kbd	1.15.5-2	Linux console font and keytable utilities
keyboard-configuration	1.123	system-wide keyboard preferences
klIBC-utils	2.0.4-2	small utilities built with klIBC for early boot
kmod	18-3	tools for managing Linux kernel modules
krb5-locales	1.12.1+dfsg-19+deb8u2	Internationalization support for MIT Kerberos
laptop-detect	0.13.7	attempt to detect a laptop
less	458-3	pager program similar to more
libacl1:amd64	2.2.52-2	Access control list shared library
libalgorithm-c3-perl	0.09-1	Perl module for merging hierarchies using the C3 algorithm
libalgorithm-diff-perl	1.19.02-3	module to find differences between files
libalgorithm-diff-xs-perl	0.04-3+b1	module to find differences between files (XS accelerated)
libalgorithm-merge-perl	0.08-2	Perl module for three-way merge of textual data
libapache2-mod-php5	5.6.24+dfsg-0+deb8u1	server-side, HTML-embedded scripting language (Apache 2 module)
libapr1:amd64	1.5.1-3	Apache Portable Runtime Library
libaprutil1:amd64	1.5.4-1	Apache Portable Runtime Utility Library
libaprutil1-dbd-sqlite3:amd64	1.5.4-1	Apache Portable Runtime Utility Library - SQLite3 Driver
libaprutil1-ldap:amd64	1.5.4-1	Apache Portable Runtime Utility Library - LDAP Driver
libapt-inst1.5:amd64	1.0.9.8.3	deb package format runtime library
libapt-pkg4.12:amd64	1.0.9.8.3	package management runtime library
libarchive-extract-perl	0.72-1	generic archive extracting module
libasan1:amd64	4.9.2-10	AddressSanitizer -- a fast memory error detector
libasprintf0c2:amd64	0.19.3-2	GNU library to use fprintf and friends in C++
libassuan0:amd64	2.1.2-2	IPC library for the GnuPG components
libatk1.0-0:amd64	2.14.0-1	ATK accessibility toolkit
libatk1.0-data	2.14.0-1	Common files for the ATK accessibility toolkit
libatomic1:amd64	4.9.2-10	support library providing __atomic built-in functions
libattr1:amd64	1:2.4.47-2	Extended attribute shared library
libaudit-common	1:2.4-1	Dynamic library for security auditing - common

Name	Version	Description
		files
libaudit1:amd64	1:2.4.1+b1	Dynamic library for security auditing
libauthen-sasl-perl	2.1600-1	Authen::SASL - SASL Authentication framework
libavahi-client3:amd64	0.6.31-5	Avahi client library
libavahi-common-data:amd64	0.6.31-5	Avahi common data files
libavahi-common3:amd64	0.6.31-5	Avahi common library
libbind9-90	1:9.9.5.dfsg-9+deb8u6	BIND9 Shared Library used by BIND
libblkid1:amd64	2.25.2-6	block device id library
libboost-iostreams1.55.0:amd64	1.55.0+dfsg-3	Boost.Iostreams Library
libbsd0:amd64	0.7.0-2	utility functions from BSD systems - shared library
libbz2-1.0:amd64	1.0.6-7+b3	high-quality block-sorting file compressor library - runtime
libc-bin	2.19-18+deb8u4	GNU C Library: Binaries
libc-dev-bin	2.19-18+deb8u4	GNU C Library: Development binaries
libc6:amd64	2.19-18+deb8u4	GNU C Library: Shared libraries
libc6-dev:amd64	2.19-18+deb8u4	GNU C Library: Development Libraries and Header Files
libcairo2:amd64	1.14.0-2.1+deb8u1	Cairo 2D vector graphics library
libcap-ng0:amd64	0.7.4-2	An alternate POSIX capabilities library
libcap2:amd64	1:2.24-8	POSIX 1003.1e capabilities (library)
libcap2-bin	1:2.24-8	POSIX 1003.1e capabilities (utilities)
libcgi-fast-perl	1:2.04-1	CGI subclass for work with FCGI
libcgipm-perl	4.09-1	module for Common Gateway Interface applications
libcilkrt5:amd64	4.9.2-10	Intel Cilk Plus language extensions (runtime)
libclass-accessor-perl	0.34-1	Perl module that automatically generates accessors
libclass-c3-perl	0.26-1	pragma for using the C3 method resolution order
libclass-c3-xs-perl	0.13-2+b1	Perl module to accelerate Class::C3
libclass-isa-perl	0.36-5	report the search path for a class's ISA tree
libcloog-isl4:amd64	0.18.2-1+b2	Chunky Loop Generator (runtime library)
libcomerr2:amd64	1.42.12-1.1	common error description library
libcpantmeta-perl	2.142690-1	Perl module to access CPAN distributions metadata
libcryptsetup4:amd64	2:1.6.6-5	disk encryption support - shared library
libcurl3-gnutls:amd64	7.38.0-4+deb8u3	easy-to-use client-side URL transfer library (GnuTLS flavour)
libcwidget3:amd64	0.5.17-2	high-level terminal interface library for C++ (runtime files)
libdaemon0:amd64	0.14-6	lightweight C library for daemons - runtime library
libdata-optlist-perl	0.109-1	module to parse and validate simple name/value option pairs
libdata-section-perl	0.200006-1	module to read chunks of data from a module's DATA section
libdatrie1:amd64	0.2.8-1	Double-array trie library
libdb5.3:amd64	5.3.28-9	Berkeley v5.3 Database Libraries [runtime]
libdbus-1-3:amd64	1.8.20-0+deb8u1	simple interprocess messaging system (library)
libdebconfclient0:amd64	0.192	Debian Configuration Management System (C-implementation library)
libdevmapper1.02.1:amd64	2:1.02.90-2.2+deb8u1	Linux Kernel Device Mapper userspace library
libdiscover2	2.1.2-7	hardware identification library

Name	Version	Description
libdns-export100	1:9.9.5.dfsg-9+deb8u6	Exported DNS Shared Library
libdns100	1:9.9.5.dfsg-9+deb8u6	DNS Shared Library used by BIND
libdpkg-perl	1.17.27	Dpkg perl modules
libedit2:amd64	3.1-20140620-2	BSD editline and history libraries
libencode-locale-perl	1.03-1	utility to determine the locale encoding
libestr0	0.1.9-1.1	Helper functions for handling strings (lib)
libevent-2.0-5:amd64	2.0.21-stable-2	Asynchronous event notification library
libexpat1:amd64	2.1.0-6+deb8u2	XML parsing C library - runtime library
libfakeroot:amd64	1.20.2-1	tool for simulating superuser privileges - shared libraries
libfcgi-perl	0.77-1+b1	helper module for FastCGI
libffi6:amd64	3.1-2+b2	Foreign Function Interface library runtime
libfile-fcntllock-perl	0.22-1+b1	Perl module for file locking with fcntl(2)
libfile-listing-perl	6.04-1	module to parse directory listings
libfont-afm-perl	1.20-1	Font::AFM - Interface to Adobe Font Metrics files
libfontconfig1:amd64	2.11.0-6.3	generic font configuration library - runtime
libfreetype6:amd64	2.5.2-3+deb8u1	FreeType 2 font engine, shared library files
libfuse2:amd64	2.9.3-15+deb8u2	Filesystem in Userspace (library)
libgc1c2:amd64	1:7.2d-6.4	conservative garbage collector for C and C++
libgcc-4.9-dev:amd64	4.9.2-10	GCC support library (development files)
libgcc1:amd64	1:4.9.2-10	GCC support library
libgcrypt20:amd64	1.6.3-2+deb8u1	LGPL Crypto library - runtime library
libgdbm3:amd64	1.8.3-13.1	GNU dbm database routines (runtime version)
libgdk-pixbuf2.0-0:amd64	2.31.1-2+deb8u4	GDK Pixbuf library
libgdk-pixbuf2.0-common	2.31.1-2+deb8u4	GDK Pixbuf library - data files
libgeoip1:amd64	1.6.2-4	non-DNS IP-to-country resolver library
libglib2.0-0:amd64	2.42.1-1+b1	GLib library of C routines
libglib2.0-data	2.42.1-1	Common files for GLib library
libgmp10:amd64	2:6.0.0+dfsg-6	Multiprecision arithmetic library
libgnutls-deb0-28:amd64	3.3.8-6+deb8u3	GNU TLS library - main runtime library
libgnutls-openssl27:amd64	3.3.8-6+deb8u3	GNU TLS library - OpenSSL wrapper
libgomp1:amd64	4.9.2-10	GCC OpenMP (GOMP) support library
libgpg-error0:amd64	1.17-3	library for common error values and messages in GnuPG components
libgpgme11:amd64	1.5.1-6	GPGME - GnuPG Made Easy (library)
libgpm2:amd64	1.20.4-6.1+b2	General Purpose Mouse - shared library
libgraphite2-3:amd64	1.3.6-1~deb8u1	Font rendering engine for Complex Scripts -- library
libgssapi-krb5-2:amd64	1.12.1+dfsg-19+deb8u2	MIT Kerberos runtime libraries - krb5 GSS-API Mechanism
libgtk2.0-0:amd64	2.24.25-3+deb8u1	GTK+ graphical user interface library
libgtk2.0-bin	2.24.25-3+deb8u1	programs for the GTK+ graphical user interface library
libgtk2.0-common	2.24.25-3+deb8u1	common files for the GTK+ graphical user interface library
libharfbuzz0b:amd64	0.9.35-2	OpenType text shaping engine (shared library)
libhogweed2:amd64	2.7.1-5+deb8u1	low level cryptographic library (public-key cryptos)
libhtml-form-perl	6.03-1	module that represents an HTML form element
libhtml-format-perl	2.11-1	module for transforming HTML into various formats
libhtml-parser-perl	3.71-1+b3	collection of modules that parse HTML text documents
libhtml-tagset-perl	3.20-2	Data tables pertaining to HTML

Name	Version	Description
libhtml-tree-perl	5.03-1	Perl module to represent and create HTML syntax trees
libhttp-cookies-perl	6.01-1	HTTP cookie jars
libhttp-daemon-perl	6.01-1	simple http server class
libhttp-date-perl	6.02-1	module of date conversion routines
libhttp-message-perl	6.06-1	perl interface to HTTP style messages
libhttp-negotiate-perl	6.00-2	implementation of content negotiation
libicu52:amd64	52.1.8+deb8u3	International Components for Unicode
libidn11:amd64	1.29-1+deb8u1	GNU Libidn library, implementation of IETF IDN specifications
libintl-perl	1.23-1	Uniforum message translations system compatible i18n library
libio-html-perl	1.001-1	open an HTML file with automatic charset detection
libio-socket-ip-perl	0.32-1	module for using IPv4 and IPv6 sockets in a protocol-independent way
libio-socket-ssl-perl	2.002-2+deb8u1	Perl module implementing object oriented interface to SSL sockets
libio-string-perl	1.08-3	Emulate IO::File interface for in-core strings
libirs-export91	1:9.9.5.dfsg-9+deb8u6	Exported IRS Shared Library
libisc-export95	1:9.9.5.dfsg-9+deb8u6	Exported ISC Shared Library
libisc95	1:9.9.5.dfsg-9+deb8u6	ISC Shared Library used by BIND
libisccc90	1:9.9.5.dfsg-9+deb8u6	Command Channel Library used by BIND
libisccfg-export90	1:9.9.5.dfsg-9+deb8u6	Exported ISC CFG Shared Library
libisccfg90	1:9.9.5.dfsg-9+deb8u6	Config File Handling Library used by BIND
libisl10:amd64	0.12.2-2	manipulating sets and relations of integer points bounded by linear cons
libitm1:amd64	4.9.2-10	GNU Transactional Memory Library
libiw30:amd64	30~pre9-8	Wireless tools - library
libjasper1:amd64	1.900.1-debian1-2.4+d	JasPer JPEG-2000 runtime library
libjbig0:amd64	2.1-3.1	JBIGkit libraries
libjpeg62-turbo:amd64	1:1.3.1-12	libjpeg-turbo JPEG runtime library
libjson-c2:amd64	0.11-4	JSON manipulation library - shared library
libk5crypto3:amd64	1.12.1+dfsg-19+deb8u2	MIT Kerberos runtime libraries - Crypto Library
libkeyutils1:amd64	1.5.9-5+b1	Linux Key Management Utilities (library)
libklibc	2.0.4-2	minimal libc subset for use with initramfs
libkmod2:amd64	18-3	libkmod shared library
libkrb5-3:amd64	1.12.1+dfsg-19+deb8u2	MIT Kerberos runtime libraries
libkrb5support0:amd64	1.12.1+dfsg-19+deb8u2	MIT Kerberos runtime libraries - Support library
libksba8:amd64	1.3.2-1+deb8u1	X.509 and CMS support library
liblcms2-2:amd64	2.6-3+b3	Little CMS 2 color management library
libldap-2.4-2:amd64	2.4.40+dfsg-1+deb8u2	OpenLDAP libraries
liblocale-gettext-perl	1.05-8+b1	module using libc functions for internationalization in Perl
liblockfile-bin	1.09-6	support binaries for and cli utilities based on liblockfile
liblockfile1:amd64	1.09-6	NFS-safe locking library
liblog-message-perl	0.8-1	powerful and flexible message logging mechanism
liblog-message-simple-perl	0.10-2	simplified interface to Log::Message
liblogging-stdlog0:amd64	1.0.4-1	easy to use and lightweight logging library
liblognorm1:amd64	1.0.1-3	Log normalizing library
liblsan0:amd64	4.9.2-10	LeakSanitizer -- a memory leak detector (runtime)
liblua5.1-0:amd64	5.1.5-7.1	Shared library for the Lua interpreter version 5.1

Name	Version	Description
liblwp-mediatypes-perl	6.02-1	module to guess media type for a file or a URL
liblwp-protocol-https-perl	6.06-2	HTTPS driver for LWP::UserAgent
liblwres90	1:9.9.5.dfsg-9+deb8u6	Lightweight Resolver Library used by BIND
liblzma5:amd64	5.1.1alpha+20120614-2	XZ-format compression library
liblzo2-2:amd64	2.08-1.2	data compression library
libmagic1:amd64	1:5.22+15-2+deb8u1	File type determination library using "magic" numbers
libmailtools-perl	2.13-1	Manipulate email in perl programs
libmnl0:amd64	1.0.3-5	minimalistic Netlink communication library
libmodule-build-perl	0.421000-2	framework for building and installing Perl modules
libmodule-pluggable-perl	5.1-1	module for giving modules the ability to have plugins
libmodule-signature-perl	0.73-1+deb8u2	module to manipulate CPAN SIGNATURE files
libmount1:amd64	2.25.2-6	device mounting library
libmpc3:amd64	1.0.2-1	multiple precision complex floating-point library
libmpfr4:amd64	3.1.2-2	multiple precision floating-point computation
libmro-compat-perl	0.12-1	mro::* interface compatibility for Perls < 5.9.5
libncurses5:amd64	5.9+20140913-1+b1	shared libraries for terminal handling
libncurses5-dev:amd64	5.9+20140913-1+b1	developer's libraries for ncurses
libncursesw5:amd64	5.9+20140913-1+b1	shared libraries for terminal handling (wide character support)
libnet-http-perl	6.07-1	module providing low-level HTTP connection client
libnet-smtp-ssl-perl	1.01-3	Perl module providing SSL support to Net::SMTP
libnet-ssleay-perl	1.65-1+b1	Perl module for Secure Sockets Layer (SSL)
libnetfilter-acct1:amd64	1.0.2-1.1	Netfilter acct library
libnettle4:amd64	2.7.1-5+deb8u1	low level cryptographic library (symmetric and one-way cryptos)
libnewt0.52:amd64	0.52.17-1+b1	Not Erik's Windowing Toolkit - text mode windowing with slang
libnfnetlink0:amd64	1.0.1-3	Netfilter netlink library
libnfsidmap2:amd64	0.25-5	NFS idmapping library
libnl-3-200:amd64	3.2.24-2	library for dealing with netlink sockets
libnl-genl-3-200:amd64	3.2.24-2	library for dealing with netlink sockets - generic netlink
libnuma1:amd64	2.0.10-1	Libraries for controlling NUMA policy
libonig2:amd64	5.9.5-3.2	Oniguruma regular expressions library
libopts25:amd64	1:5.18.4-3	automated option processing library based on autogen
libp11-kit0:amd64	0.20.7-1	Library for loading and coordinating access to PKCS#11 modules - runtime
libpackage-constants-perl	0.04-1	List constants defined in a package
libpam-modules:amd64	1.1.8-3.1+deb8u1+b1	Pluggable Authentication Modules for PAM
libpam-modules-bin	1.1.8-3.1+deb8u1+b1	Pluggable Authentication Modules for PAM - helper binaries
libpam-runtime	1.1.8-3.1+deb8u1	Runtime support for the PAM library
libpam0g:amd64	1.1.8-3.1+deb8u1+b1	Pluggable Authentication Modules library
libpango-1.0-0:amd64	1.36.8-3	Layout and rendering of internationalized text
libpangocairo-1.0-0:amd64	1.36.8-3	Layout and rendering of internationalized text
libpangoft2-1.0-0:amd64	1.36.8-3	Layout and rendering of internationalized text
libpaper-utils	1.1.24+nmu4	library for handling paper characteristics (utilities)
libpaper1:amd64	1.1.24+nmu4	library for handling paper characteristics
libparams-util-perl	1.07-2+b1	Perl extension for simple stand-alone param

Name	Version	Description
		checking functions
libparse-debianchangelog-perl	1.2.0-1.1	parse Debian changelogs and output them in other formats
libpci3:amd64	1:3.2.1-3	Linux PCI Utilities (shared library)
libpcre3:amd64	2:8.35-3.3+deb8u4	Perl 5 Compatible Regular Expression Library - runtime files
libpcslite1:amd64	1.8.13-1	Middleware to access a smart card using PC/SC (library)
libperl-dev	5.20.2-3+deb8u6	Perl library: development files
libperl4-corelibs-perl	0.003-1	libraries historically supplied with Perl 4
libperl5.20	5.20.2-3+deb8u6	shared Perl library
libpipeline1:amd64	1.4.0-1	pipeline manipulation library
libpixman-1-0:amd64	0.32.6-3	pixel-manipulation library for X and cairo
libpkcs11-helper1:amd64	1.11-2	library that simplifies the interaction with PKCS#11
libpng12-0:amd64	1.2.50-2+deb8u2	PNG library - runtime
libpod-latex-perl	0.61-1	module to convert Pod data to formatted LaTeX
libpod-readme-perl	0.11-1	Perl module to convert POD to README file
libpopt0:amd64	1.16-10	lib for parsing cmdline parameters
libprocps3:amd64	2:3.3.9-9	library for accessing process information from /proc
libpsl0:amd64	0.5.1-1	Library for Public Suffix List (shared libraries)
libpth20:amd64	2.0.7-20	GNU Portable Threads
libpython-stdlib:amd64	2.7.9-1	interactive high-level object-oriented language (default python version)
libpython2.7-minimal:amd64	2.7.9-2	Minimal subset of the Python language (version 2.7)
libpython2.7-stdlib:amd64	2.7.9-2	Interactive high-level object-oriented language (standard library, versi
libqdbm14	1.8.78-5+b1	QDBM Database Libraries without GDBM wrapper[runtime]
libquadmath0:amd64	4.9.2-10	GCC Quad-Precision Math Library
libreadline6:amd64	6.3-8+b3	GNU readline and history libraries, run-time libraries
libregexp-common-perl	2013031301-1	module with common regular expressions
librtmp1:amd64	2.4+20150115.gita107c	toolkit for RTMP streams (shared library)
libsasl2-2:amd64	2.1.26.dfsg1-13+deb8u	Cyrus SASL - authentication abstraction library
libsasl2-modules:amd64	2.1.26.dfsg1-13+deb8u	Cyrus SASL - pluggable authentication modules
libsasl2-modules-db:amd64	2.1.26.dfsg1-13+deb8u	Cyrus SASL - pluggable authentication modules (DB)
libselinux1:amd64	2.3-2	SELinux runtime shared libraries
libsemanage-common	2.3-1	Common files for SELinux policy management libraries
libsemanage1:amd64	2.3-1+b1	SELinux policy management library
libsensors4:amd64	1:3.3.5-2	library to read temperature/voltage/fan sensors
libsepolicy1:amd64	2.3-2	SELinux library for manipulating binary security policies
libsigc++-2.0-0c2a:amd64	2.4.0-1	type-safe Signal Framework for C++ - runtime
libsigsegv2:amd64	2.10-4+b1	Library for handling page faults in a portable way
libslang2:amd64	2.3.0-2	S-Lang programming library - runtime version
libsmartcols1:amd64	2.25.2-6	smart column output alignment library
libsntp-base	5.7.2.1+dfsg-1	SNMP configuration script, MIBs and documentation

Name	Version	Description
libsntp30:amd64	5.7.2.1+dfsg-1	SNMP (Simple Network Management Protocol) library
libsoftware-license-perl	0.103010-3	module providing templated software licenses
libsqLite3-0:amd64	3.8.7.1-1+deb8u1	SQLite 3 shared library
libsqLite3-dev:amd64	3.8.7.1-1+deb8u1	SQLite 3 development files
libss2:amd64	1.42.12-1.1	command-line interface parsing library
libssh2-1:amd64	1.4.3-4.1+deb8u1	SSH2 client-side library
libssl1.0.0:amd64	1.0.1t-1+deb8u2	Secure Sockets Layer toolkit - shared libraries
libstdc++-4.9-dev:amd64	4.9.2-10	GNU Standard C++ Library v3 (development files)
libstdc++-6:amd64	4.9.2-10	GNU Standard C++ Library v3
libsub-exporter-perl	0.986-1	sophisticated exporter for custom-built routines
libsub-install-perl	0.928-1	module for installing subroutines into packages easily
libsub-name-perl	0.12-1	module for assigning a new name to referenced sub
libswitch-perl	2.17-2	switch statement for Perl
libsystemd0:amd64	215-17+deb8u4	systemd utility library
libtasn1-6:amd64	4.2-3+deb8u2	Manage ASN.1 structures (runtime)
libterm-ui-perl	0.42-1	Term::ReadLine UI made easy
libtext-charwidth-perl	0.04-7+b3	get display widths of characters on the terminal
libtext-iconv-perl	1.7-5+b2	converts between character sets in Perl
libtext-soundex-perl	3.4-1+b2	implementation of the soundex algorithm
libtext-template-perl	1.46-1	perl module to process text templates
libtext-unidecode-perl	1.22-1	Text::Unidecode -- US-ASCII transliterations of Unicode text
libtext-wrapi8n-perl	0.06-7	internationalized substitute of Text::Wrap
libthai-data	0.1.21-1	Data files for Thai language support library
libthai0:amd64	0.1.21-1	Thai language support library
libtiff5:amd64	4.0.3-12.3+deb8u1	Tag Image File Format (TIFF) library
libtimedate-perl	2.3000-2	collection of modules to manipulate date/time information
libtinfo-dev:amd64	5.9+20140913-1+b1	developer's library for the low-level terminfo library
libtinfo5:amd64	5.9+20140913-1+b1	shared low-level terminfo library for terminal handling
libtirpc1:amd64	0.2.5-1	transport-independent RPC library
libtokyocabinet9:amd64	1.4.48-3	Tokyo Cabinet Database Libraries [runtime]
libtsan0:amd64	4.9.2-10	ThreadSanitizer -- a Valgrind-based detector of data races (runtime)
libubsan0:amd64	4.9.2-10	UBSan -- undefined behaviour sanitizer (runtime)
libudev1:amd64	215-17+deb8u4	libudev shared library
liburi-perl	1.64-1	module to manipulate and access URI strings
libusb-0.1-4:amd64	2:0.1.12-25	userspace USB programming library
libusb-1.0-0:amd64	2:1.0.19-1	userspace USB programming library
libustr-1.0-1:amd64	1.0.4-3+b2	Micro string library: shared library
libuuid1:amd64	2.25.2-6	Universally Unique ID library
libwebp5:amd64	0.4.1-1.2+b2	Lossy compression of digital photographic images.
libwebpdemux1:amd64	0.4.1-1.2+b2	Lossy compression of digital photographic images.
libwebpmux1:amd64	0.4.1-1.2+b2	Lossy compression of digital photographic images.
libwrap0:amd64	7.6.q-25	Wietse Venema's TCP wrappers library
libwww-perl	6.08-1	simple and consistent interface to the world-wide web

Name	Version	Description
libwww-robotrules-perl	6.01-1	database of robots.txt-derived permissions
libx11-6:amd64	2:1.6.2-3	X11 client-side library
libx11-data	2:1.6.2-3	X11 client-side library
libx86-1:amd64	1.1+ds1-10	x86 real-mode library
libxapian22	1.2.19-1+deb8u1	Search engine library
libxau6:amd64	1:1.0.8-1	X11 authorisation library
libxcb-render0:amd64	1.10-3+b1	X C Binding, render extension
libxcb-shm0:amd64	1.10-3+b1	X C Binding, shm extension
libxcb1:amd64	1.10-3+b1	X C Binding
libxcomposite1:amd64	1:0.4.4-1	X11 Composite extension library
libxcursor1:amd64	1:1.1.14-1+b1	X cursor management library
libxdamage1:amd64	1:1.1.4-2+b1	X11 damaged region extension library
libxdmcp6:amd64	1:1.1.1-1+b1	X11 Display Manager Control Protocol library
libxext6:amd64	2:1.3.3-1	X11 miscellaneous extension library
libxfixed3:amd64	1:5.0.1-2+b2	X11 miscellaneous 'fixed' extension library
libxi6:amd64	2:1.7.4-1+b2	X11 Input extension library
libxinerama1:amd64	2:1.1.3-1+b1	X11 Xinerama extension library
libxml-libxml-perl	2.0116+dfsg-1+deb8u1	Perl interface to the libxml2 library
libxml-namespacesupport-perl	1.11-1	Perl module for supporting simple generic namespaces
libxml-parser-perl	2.41-3	Perl module for parsing XML files
libxml-sax-base-perl	1.07-1	base class for SAX drivers and filters
libxml-sax-expat-perl	0.40-2	Perl module for a SAX2 driver for Expat (XML::Parser)
libxml-sax-perl	0.99+dfsg-2	Perl module for using and building Perl SAX2 XML processors
libxml2:amd64	2.9.1+dfsg1-5+deb8u1	GNOME XML library
libxmui1:amd64	2:1.1.2-1	X11 miscellaneous micro-utility library
libxrandr2:amd64	2:1.4.2-1+b1	X11 RandR extension library
libxrender1:amd64	1:0.9.8-1+b1	X Rendering Extension client library
libxtables10	1.4.21-2+b1	netfilter xtables library
linux-base	4.3~bpo8+1	Linux image base package
linux-compiler-gcc-4.9-x86	4.6.4-1~bpo8+1	Compiler for Linux on x86 (meta-package)
linux-headers-4.6.0-0.bpo.1-amd64	4.6.4-1~bpo8+1	Header files for Linux 4.6.0-0.bpo.1-amd64
linux-headers-4.6.0-0.bpo.1-common	4.6.4-1~bpo8+1	Common header files for Linux 4.6.0-0.bpo.1
linux-image-4.6.0-0.bpo.1-amd64	4.6.4-1~bpo8+1	Linux 4.6 for 64-bit PCs
linux-kbuild-4.6	4.6.4-1~bpo8+1	Kbuild infrastructure for Linux 4.6
linux-libc-dev:amd64	4.6.4-1~bpo8+1	Linux support headers for userspace development
lm-sensors	1:3.3.5-2	utilities to read temperature/voltage/fan sensors
locales	2.19-18+deb8u4	GNU C Library: National Language (locale) data [support]
lockfile-progs	0.1.17	Programs for locking and unlocking files and mailboxes
login	1:4.2-3+deb8u1	system login tools
logrotate	3.8.7-1+b1	Log rotation utility
lsb-base	4.1+Debian13+nmu1	Linux Standard Base 4.1 init script functionality
lsb-release	4.1+Debian13+nmu1	Linux Standard Base version reporting utility
lshw	02.17-1.1	information about hardware configuration
lsof	4.86+dfsg-1	Utility to list open files

Name	Version	Description
m4	1.4.17-4	macro processing language
make	4.0-8.1	utility for directing compilation
man-db	2.7.0.2-5	on-line manual pager
manpages	3.74-1	Manual pages about using a GNU/Linux system
manpages-dev	3.74-1	Manual pages about using GNU/Linux for development
mawk	1.3.3-17	a pattern scanning and text processing language
mime-support	3.58	MIME files 'mime.types' & 'mailcap', and support programs
mlocate	0.26-1	quickly find files on the filesystem based on their name
mount	2.25.2-6	Tools for mounting and manipulating filesystems
multiarch-support	2.19-18+deb8u4	Transitional package to ensure multiarch compatibility
mutt	1.5.23-3	text-based mail reader supporting MIME, GPG, PGP and threading
nano	2.2.6-3	small, friendly text editor inspired by Pico
ncurses-base	5.9+20140913-1	basic terminal type definitions
ncurses-bin	5.9+20140913-1+b1	terminal-related programs and man pages
ncurses-term	5.9+20140913-1	additional terminal type definitions
net-tools	1.60-26+b1	NET-3 networking toolkit
netbase	5.3	Basic TCP/IP networking system
netcat-traditional	1.10-41	TCP/IP swiss army knife
nfacct	1.0.1-1.1	netfilter accounting object tool
nfs-common	1:1.2.8-9	NFS support files common to client and server
ntp	1:4.2.6.p5+dfsg-7+deb	Network Time Protocol daemon and utility programs
ntpdate	1:4.2.6.p5+dfsg-7+deb	client for setting system time from NTP servers
opensc	0.14.0-2	Smart card utilities with support for PKCS#15 compatible cards
opensc-pkcs11:amd64	0.14.0-2	Smart card utilities with support for PKCS#15 compatible cards
openssh-client	1:6.7p1-5+deb8u3	secure shell (SSH) client, for secure access to remote machines
openssh-server	1:6.7p1-5+deb8u3	secure shell (SSH) server, for secure access from remote machines
openssh-sftp-server	1:6.7p1-5+deb8u3	secure shell (SSH) sftp server module, for SFTP access from remote machines
openssl	1.0.1t-1+deb8u2	Secure Sockets Layer toolkit - cryptographic utility
openvpn	2.3.4-5+deb8u1	virtual private network daemon
os-prober	1.65	utility to detect other OSes on a set of drives
passwd	1:4.2-3+deb8u1	change and administer password and group data
patch	2.7.5-1	Apply a diff file to an original
pciutils	1:3.2.1-3	Linux PCI Utilities
perl	5.20.2-3+deb8u6	Larry Wall's Practical Extraction and Report Language
perl-base	5.20.2-3+deb8u6	minimal Perl system
perl-modules	5.20.2-3+deb8u6	Core Perl modules
php5	5.6.24+dfsg-0+deb8u1	server-side, HTML-embedded scripting language (metapackage)
php5-cli	5.6.24+dfsg-0+deb8u1	command-line interpreter for the php5 scripting language

Name	Version	Description
php5-common	5.6.24+dfsg-0+deb8u1	Common files for packages built from the php5 source
php5-json	1.3.6-1	JSON module for php5
php5-readline	5.6.24+dfsg-0+deb8u1	Readline module for php5
pinentry-gtk2	0.8.3-2	GTK+-2-based PIN or pass-phrase entry dialog for GnuPG
pm-utils	1.4.1-15	utilities and scripts for power management
pmount	0.9.23-3+b1	mount removable devices as normal user
powermgmt-base	1.31+nmu1	Common utils and configs for power management
powertop	2.6.1-1	diagnose issues with power consumption and management
procmail	3.22-24	Versatile e-mail processor
procps	2:3.3.9-9	/proc file system utilities
psmisc	22.21-2	utilities that use the proc file system
python	2.7.9-1	interactive high-level object-oriented language (default version)
python-apt	0.9.3.12	Python interface to libapt-pkg
python-apt-common	0.9.3.12	Python interface to libapt-pkg (locales)
python-chardet	2.3.0-1	universal character encoding detector for Python2
python-debian	0.1.27	Python modules to work with Debian-related data formats
python-debianbts	1.12	Python interface to Debian's Bug Tracking System
python-defusedxml	0.4.1-2	XML bomb protection for Python stdlib modules (for Python 2)
python-docutils	0.12+dfsg-1	text processing system for reStructuredText (implemented in Python 2)
python-minimal	2.7.9-1	minimal subset of the Python language (default version)
python-pil:amd64	2.6.1-2+deb8u2	Python Imaging Library (Pillow fork)
python-pkg-resources	5.5.1-1	Package Discovery and Resource Access using pkg_resources
python-pygments	2.0.1+dfsg-1.1+deb8u1	syntax highlighting package written in Python
python-reportbug	6.6.3	Python modules for interacting with bug tracking systems
python-roman	2.0.0-1	module for generating/analyzing Roman numerals for Python 2
python-six	1.8.0-1	Python 2 and 3 compatibility library (Python 2 interface)
python-soappy	0.12.22-1	SOAP Support for Python
python-support	1.0.15	automated rebuilding support for Python modules
python-wstools	0.4.3-2	WSDL parsing tools Python module
python2.7	2.7.9-2	Interactive high-level object-oriented language (version 2.7)
python2.7-minimal	2.7.9-2	Minimal subset of the Python language (version 2.7)
racoon	1:0.8.2+20140711-2+de	IPsec Internet Key Exchange daemon
read-edid	3.0.1-2	hardware information-gathering tool for VESA PnP monitors
readline-common	6.3-8	GNU readline and history libraries, common files
rename	0.20-3	Perl extension for renaming multiple files
reportbug	6.6.3	reports bugs in the Debian distribution

Name	Version	Description
rpcbind	0.2.1-6+deb8u1	converts RPC program numbers into universal addresses
rsync	3.1.1-3	fast, versatile, remote (and local) file-copying tool
rsyslog	8.4.2-1+deb8u2	reliable system and kernel logging daemon
sed	4.2.2-4+b1	The GNU sed stream editor
sensible-utils	0.0.9	Utilities for sensible alternative selection
sgml-base	1.26+nmu4	SGML infrastructure and SGML catalog file support
shared-mime-info	1.3-1	FreeDesktop.org shared MIME database and spec
snmp	5.7.2.1+dfsg-1	SNMP (Simple Network Management Protocol) applications
snmpd	5.7.2.1+dfsg-1	SNMP (Simple Network Management Protocol) agents
sqlite3	3.8.7.1-1+deb8u1	Command line interface for SQLite 3
ssh	1:6.7p1-5+deb8u3	secure shell client and server (metapackage)
ssl-cert	1.0.35	simple debconf wrapper for OpenSSL
startpar	0.59-3	run processes in parallel and multiplex their output
sudo	1.8.10p3-1+deb8u3	Provide limited super user privileges to specific users
sysstat	11.0.1-1	system performance tools for Linux
systemd	215-17+deb8u4	system and service manager
systemd-sysv	215-17+deb8u4	system and service manager - SysV links
sysv-rc	2.88dsf-59	System-V-like run level change mechanism
sysvinit-utils	2.88dsf-59	System-V-like utilities
tar	1.27.1-2+b1	GNU version of the tar archiving utility
task-english	3.31+deb8u1	General English environment
task-laptop	3.31+deb8u1	laptop
task-ssh-server	3.31+deb8u1	SSH server
tasksel	3.31+deb8u1	tool for selecting tasks for installation on Debian systems
tasksel-data	3.31+deb8u1	official tasks used for installation of Debian systems
tcpd	7.6.q-25	Wietse Venema's TCP wrapper utilities
texinfo	5.2.0.dfsg.1-6	Documentation system for on-line information and printed output
time	1.7-25	GNU time program for measuring CPU resource usage
traceroute	1:2.0.20-2+b1	Traces the route taken by packets over an IPv4/IPv6 network
tzdata	2016d-0+deb8u1	time zone and daylight-saving time data
ucf	3.0030	Update Configuration File(s): preserve user changes to config files
udev	215-17+deb8u4	/dev/ and hotplug management daemon
usbmount	0.0.22	automatically mount and unmount USB mass storage devices
usbutils	1:007-2	Linux USB utilities
util-linux	2.25.2-6	Miscellaneous system utilities
util-linux-locales	2.25.2-6	Locales files for util-linux
vbetool	1.1-3	run real-mode video BIOS code to alter hardware state
vim	2:7.4.488-7	Vi IMproved - enhanced vi editor
vim-common	2:7.4.488-7	Vi IMproved - Common files
vim-runtime	2:7.4.488-7	Vi IMproved - Runtime files

Name	Version	Description
vim-tiny	2:7.4.488-7	Vi IMproved - enhanced vi editor - compact version
w3m	0.5.3-19	WWW browsable pager with excellent tables/frames support
wamerican	7.1-1	American English dictionary words for /usr/share/dict
watchdog	5.14-3	system health checker and software/hardware watchdog handler
wget	1.16-1	retrieves files from the web
whiptail	0.52.17-1+b1	Displays user-friendly dialog boxes from shell scripts
whois	5.2.7	intelligent WHOIS client
wireless-regdb	2014.11.18-1	wireless regulatory database
wireless-tools	30~pre9-8	Tools for manipulating Linux Wireless Extensions
wpa_supplicant	2.3-1+deb8u3	client support for WPA and WPA2 (IEEE 802.11i)
xauth	1:1.0.9-1	X authentication utility
xdg-user-dirs	0.15-2	tool to manage well known user directories
xkb-data	2.12-1	X Keyboard Extension (XKB) configuration data
xml-core	0.13+nmu2	XML infrastructure and XML catalog file support
xz-utils	5.1.1alpha+20120614-2	XZ-format compression utilities
zlib1g:amd64	1:1.2.8.dfsg-2+b1	compression library - runtime